

HP64000 Logic Development System

Model 64515C PROM Programmer Module



CERTIFICATION

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Bureau of Standards, to the extent allowed by the Bureau's calibration facility, and to the calibration facilities of other International Standards Organization members.

WARRANTY

This Hewlett-Packard system product is warranted against defects in materials and workmanship for a period of 90 days from date of installation. During the warranty period, HP will, at its options, either repair or replace products which prove to be defective.

Warranty service of this product will be performed at Buyer's facility at no charge within HP service travel areas. Outside HP service travel areas, warranty service will be performed at Buyer's facility only upon HP's prior agreement and Buyer shall pay HP's round trip travel expenses. In all other cases, products must be returned to a service facility designated by HP.

For products returned to HP for warranty service. Buyer shall prepay shipping charges to HP and HP shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to HP from another country.

HP warrants that its software and firmware designated by HP for use with an instrument will execute its programming instructions when properly installed on that instrument. HP does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. HP SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. HP SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

ASSISTANCE

Product maintenance agreements and other customer assistance agreements are available for Hewlett-Packard products.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

CW&A 2/81





BUSINESS REPLY CARD

FIRST CLASS PERMIT NO. 1303 COLORADO SPRINGS, COLORADO

POSTAGE WILL BE PAID BY ADDRESSEE

HEWLETT-PACKARD

Logic Product Support Dept.
Attn: Technical Publications Manager
Centennial Annex - D2
P.O. Box 617
Colorado Springs, Colorado 80901-0617

NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES

FOLD HERE

Your cooperation in completing and returning this form will be greatly appreciated. Thank you.

READER COMMENT SHEET

Service Manual, Model 64515C PROM Programmer Module 64515-90903, November 1983

Your comments are important to us. Please answer this questionaire and return it to us. Circle the number that best describes your answer in questions 1 through 7. Thank you.

1.	The information in this book is complete:						
	Doesn't cover enough (what more do you need?)	1	2	3	4	5	Covers everything
2.	The information in this book is accurate:						
	Too many errors	1	2	3	4	5	Exactly right
3.	The information in this book is easy to find:						
	I can't find things I need	1	2	3	4	5	I can find info quickly
4.	The Index and Table of Contents are useful:						
	Helpful	1	2	3	4	5	Missing or inadequate
5.	What about the "how-to" procedures and ex-	amp	les:				
	No help	1	2	3	4	5	Very helpful
	Too many now	1	2	3	4	5	I'd like more
6.	What about the writing style:						
	Confusing	1	2	3	4	5	Clear
7.	What about organization of the book:						
	Poor order	1	2	3	4	5	Good order
8.	What about the size of the book:						
	too big/small	1	2	3	4	5	Right size
С	omments:						
-							
Pa	articular pages with errors?						
Na	ame (optional):						
Jo	b title:						
Co	ompany:						
Αc	ddress:						

Note: If mailed outside U.S.A., place card in envelope. Use address shown on other side of this card.





BUSINESS REPLY CARD

FIRST CLASS PERMIT NO. 1303 COLORADO SPRINGS, COLORADO

POSTAGE WILL BE PAID BY ADDRESSEE

HEWLETT-PACKARD

Logic Product Support Dept.
Attn: Technical Publications Manager
Centennial Annex - D2
P.O. Box 617
Colorado Springs, Colorado 80901-0617

NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES

FOLD HERE

Your cooperation in completing and returning this form will be greatly appreciated. Thank you.

READER COMMENT SHEET

Service Manual, Model 64515C PROM Programmer Module 64515-90903, November 1983

Your comments are important to us. Please answer this questionaire and return it to us. Circle the number that best describes your answer in questions 1 through 7. Thank you.

1.	The information in this book is complete:						
	Doesn't cover enough (what more do you need?)	1	2	3	4	5	Covers everything
2.	The information in this book is accurate:						
	Too many errors	1	2	3	4	5	Exactly right
3.	The information in this book is easy to find:						
	I can't find things I need	1	2	3	4	5	I can find info quickly
4.	The Index and Table of Contents are useful:						
	Helpful	1	2	3	4	5	Missing or inadequate
5.	What about the "how-to" procedures and ex-	amp	les:				
	No help	1	2	3	4	5	Very helpful
	Too many now	1	2	3	4	5	I'd like more
6.	What about the writing style:						
	Confusing	1	2	3	4	5	Clear
7.	What about organization of the book:						
	Poor order	1	2	3	4	5	Good order
8.	What about the size of the book:						
	too big/small	1	2	3	4	5	Right size
С	omments:						
-							
Pa	articular pages with errors?						
Na	ame (optional):						
Jo	b title:						
Co	ompany:						
Αc	ddress:						

Note: If mailed outside U.S.A., place card in envelope. Use address shown on other side of this card.

SERVICE MANUAL

MODEL 64515C

PROM PROGRAMMER MODULE

© COPYRIGHT HEWLETT-PACKARD COMPANY 1981, 1982, 1983 LOGIC SYSTEMS DIVISION COLORADO SPRINGS, COLORADO, U.S.A.

ALL RIGHTS RESERVED

Manual Part Number: 64515-90903

Printed: November 1983

SAFETY SUMMARY

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Hewlett-Packard Company assumes no liability for the customer's failure to comply with these requirements.

GROUND THE INSTRUMENT.

To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical ground. The instrument is equipped with a three-conductor ac power cable. The power cable must either be plugged into an approved three-contact electrical outlet or used with a three-contact to two-contact adapter with the grounding wire (green) firmly connected to an electrical ground (safety ground) at the power outlet. The power jack and mating plug of the power cable meet International Electrotechnical Commission (IEC) safety standards.

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE.

Do not operate the instrument in the presence of flammable gases or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

KEEP AWAY FROM LIVE CIRCUITS.

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

DO NOT SERVICE OR ADJUST ALONE.

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT.

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification of the instrument. Return the instrument to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

DANGEROUS PROCEDURE WARNINGS.

Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.

WARNING

Dangerous voltages, capable of causing death, are present in this instrument. Use extreme caution when handling, testing, and adjusting.

Table of Contents

Section	Title	Page
I	General Information	1-1
	1-1. Introduction	
II	Installation and Removal	2-1
III	Operation	3-1
IV	Performance Verification	4-1
	4-1. Introduction	
V	Adjustments	5-1
VI	Replaceable Parts	6-1
	6-1. Introduction	6-1 6-1 6-2
VII	Manual Changes	7-1
VIII	Theory and Schematics	8-1
	8-1. Introduction	

List of Illustrations

Figure	Title	Page
1-1. 4-1.	Model 64515C PROM Programmer Module	
8-1. 8-2. 8-3. 8-4. 8-5. 8-6.	Timing Diagram for the 2564	8-7 8-8 8-9 8-10

List of Tables

Fable	Title	Page
1-1.	Applicable PROM Devices	1-2
6-1.	Abbreviations and Reference Designators	6-3
6-2.	Replaceable Parts	
6-3.	Manufacturers' Codes	
8-1.	MODE selection	8-2
8-2.	Program/Verify Sequence for the 2564	8-3
8-3.	Program/Verify Sequence for the 2764/27128 and 2764A/27128A	8 - 4
8-4.	Program/Verify Sequence for the 27256	

SECTION I

GENERAL INFORMATION

1-1. INTRODUCTION.

1-2. This manual contains technical information concerning the application, troubleshooting, replacing failed parts, and the theory-of-operation for the Model 64515C PROM Programmer Module as used in the 64000 Logic Development System. The module is shown in figure 1-1.



Figure 1-1. Model 64515C PROM Programmer Module

1-3. SAFETY CONSIDERATIONS.

1-4. There are no electrical shock hazards associated with the Model 64515C since there are no high voltages present. There are, however, high voltages associated with the 64100A Mainframe and appropriate warnings are given in the Mainframe Tab where these hazards exist.

1-5. INSTRUMENTS COVERED BY THIS MANUAL.

1-6. This manual covers the model 64515C PROM Programmer Module with the 64515-66504 or 64515-66505 PC board installed. A module manufactured after the print date of this manual may contain a PC board with a later revision letter.

- 1-7. The manual for a modified module will be accompanied by a "Manual Change" supplement. This supplement will be delivered with each modified module and will contain change information that explains how to adapt this manual to the newer modified module.
- 1-8. In addition to change information, the supplement will contain information for correcting errors in this manual. To keep this manual as current as possible, Hewlett-Packard recomends that you periodically request the latest manual changes supplement. The supplement for this manual is identified with the model number and manual print date both of which appear on the title page. Complimentary copies of the supplement are available from Hewlett-Packard Sales/Service Office.
- 1-9. For information concerning the applicability of this manual or the Manual Changes supplement, contact your nearest Hewlett-Packard Sales/Service Office.

1-10. APPLICATION.

1-11. The Model 64515C will program and/or readout the integral EPROMs listed in table 1.

Table 1-1. Applicable EPROM Devices

EPROM	Mfg.	Description
2564	TI	The TMS 2564 is a 65,536 bit, ultraviolet light erasable, electronically programable read only memory.
2764/2764A	Intel	The Intel 2764/2764A is a 65,536 bit ultraviolet light erasable and electronically programable read-only memory.
27128/27128A	Intel	The Intel 27128/27128A is a 5v only, 131,072 bit ultraviolet erasable and electronically programmable read-only memory.
27256	Intel	The Intel 27256 is a 262,144 bit ultraviolet erasable and electronically programmable read-only memory.

SECTION II

INSTALLATION AND REMOVAL

- 2-1. A 50-pin ribbon cable (HP P/N 8120-3346) connects the 64501A Programmer Controller PCB to the 64515C Programmer Module. The cable end with the single connector is connected to the Controller PCB and the end with the double connector is connected to the Programmer Module.
- 2-2. The cable should be routed across the top of the cardcage and down behind the front panel such that the two connectors are visible in the opening for the programmer module. Connect the cable to the PCB in the Programmer Module using the connector on the extreme end of the cable.

NOTE

The PCB and cable connectors are keyed and fit only one way.

* To prevent possible damage to the PROM Programmer circuits, turn Mainframe power OFF before installing or removing the Programmer Module.

SECTION III

OPERATION

The operation of the 64515C is a function of the system software. Complete operation from the keyboard of the system is beyond the scope of the Service Manual. Please refer to the Operator's Manual for the procedure.

* The proper operation of the positive PROM *
programmer requires that a PROM be inserted *
ONLY AFTER the PROM programmer software *
module is called and that the PROM be RE- *
MOVED before the PROM programmer software *
module is exited. Damage to the PROM may *
result if this procedure is not followed! *
*

NOTE

The PROM programmer software module is called by pressing the "prom_prog" softkey then the Return key. To exit the PROM programmer software module, press the "end" softkey, then the Return key.

SECTION IV

PERFORMANCE VERIFICATION

4-1. INTRODUCTION.

4-2. This section normally contains the information for running the Performance Verification. However, due to the relative low cost of the PROM Programmer PC board, in this module, it is most likely more economical to discard it if it fails than to have the Hewlett-Packard Sales/Service repair it. The basic troubleshooting approach is to first determine if the Prom Controller PC board is at fault, or if the problem is in the module. This is done by using the 64502A PROM Programmer Module in conjunction with the 64501A controller board and running the PROM Performance Verification Tests.

4-3. PROCEDURE.

4-4. If a PROM programming problem is apparent (i.e., you can't sucessfully program and verify a particular PROM chip), perform the following troubleshooting procedure:

- a. Turn OFF the mainframe power.
- b. Install a 64502A PROM Programmer Module in place of the currently installed 64515C model.

- c. Turn ON the mainframe power.
- d. Refer to Section IV of the 64500S Positive PROM Programmer Tab and run the PV tests described in that Section.
- e. If there are no error messages while running the PV test, it is reasonable to assume that this PROM Programmer Module has failed. In this case, refer to the Illustrated Parts Breakdown (figure 4-1) and replace the PC board assembly (HP P/N 64515-66504 or 64515-66505).

NOTE

Section VIII describes the functions performed by the 64515C PC board.

d. Verify that the problem has been fixed by attempting to program and verify from a PROM chip like the type that was originally causing problems.




Figure 4-1. Model 64515C Illustrated Parts Breakdown

SECTION V

ADJUSTMENTS

5-1. The 64515C PROM Programmer Module has no adjustments.

SECTION VI

REPLACEABLE PARTS

6-1. INTRODUCTION.

6-2. This section contains information for ordering parts. Table 6-1 lists abbreviations used in the parts list and throughout the manual. Table 6-2 lists all replaceable parts in reference designator order. Table 6-3 contains the names and addresses that correspond to the manufacturers' five-digit code numbers.

6-3. ABBREVIATIONS.

6-4. Table 6-1 lists abbreviations used in the parts list, the schematics and throughout the manual. In some cases, two forms of the abbreviation are used: one all in capital letters, and one partial or no capitals. This occurs because the abbreviations in the parts list are always capitals. However, in the schematics and other parts of the manual, other abbreviation forms are used with both lowercase and uppercase letters.

6-5. REPLACEABLE PARTS LIST.

- 6-6. Table 6-2 is the list of replaceable parts and is organized as follows:
 - a. Chassis-mounted parts in alphanumerical order by reference designation.
 - b. Electrical assemblies and their components in alphanumerical order by reference designation.
 - c. Miscellaneous parts.

The information given for each part consists of the following:

- a. The Hewlett-Packard part number and the check digit.
- b. The total quantity (Qty) in the instrument.
- c. The description of the part.
- d. A five-digit code that indicates the manufacturer.
- e. The manufacturer's part number.

The total quantity for each part is given only once - at the first appearance of the part number in the list.

- 6-7. ORDERING INFORMATION.
- 6-8. To order a part listed in the replaceable parts table, quote the Hewlett-Packard part number and check digit, indicate the quantity required, and address the order to the nearest Hewlett-Packard Sales/Service office.
- 6-9. To order a part that is not listed in the replaceable parts table, include the instrument model number, instrument repair number, the description and function of the part, and the number of parts required. Address the order to the nearest Hewlett-Packard Sales/Service office.
- 6-10. DIRECT MAIL ORDER SYSTEM.
- 6-11. Within the U.S.A., Hewlett-Packard can supply parts through a direct mail order system. Advantages of using the system are as follows:
 - a. Direct ordering and shipment from the HP Parts Center in Mountain View, California.
 - b. No maximum or minimum on any mail order (there is a minimum order amount, for parts ordered through a local HP office when the orders require billing and invoicing).
 - c. Prepaid transportation (there is a small handling charge for each order).
 - d. No invoices to provide these advantages, a check or money order must accompany each order.
- 6-12. Mail-order forms and specific ordering information are available through your local HP office. Addresses and phone numbers are located at the back of this manual.

Table 6-1. Reference Designators and Abbreviations

REFERENCE DESIGNATORS									
A	= assembly	F	= fuse	MP	= mechanical part	U	= integrated circuit		
В	= motor	FL	= filter	P.	= plug	v	= vacuum, tube, neor		
ВТ	- battery	IC	= integrated circuit	Q	= transistor		bulb, photocell, etc		
C	= capacitor	J	= jack	R	= resistor	VR	= voltage regulator		
CP	= coupler	K	= relay	RT	= thermistor	w	= cable		
CR	= diode	L	= inductor	s	= switch	x	= socket		
DL	= delay line	LS	= loud speaker	T	= transformer	Y	= crystal		
DS	= device signaling (lamp)	м	= meter	TB	= terminal board	Z	= tuned cavity netwo		
E	= misc electronic part	MK	= microphone	TP	= test point				
			ABBF	REVIATIONS					
A	= amperes	Н	= henries	N/O	= normally open	RMO	= rack mount only		
AFC	 automatic frequency control 	HDW	= hardware	NOM	= nominal	RMS	= root-mean square		
AMPL	= amplifier	HEX	= hexagonal	NPO	= negative positive zero	RWV	= reverse working		
		HG	= mercury		(zero temperature		voltage		
BFO	= beat frequency oscillator	HR	= hour(s)		coefficient)				
BE CU	= beryllium copper	HZ	= hertz	NPN	= negative-positive-	S-B	= slow-blow		
BH	= binder head				negative	SCR	screw		
BP	= bandpass			NRFR	= not recommended for	SE	= selenium		
BRS	= brass	IF.	= intermediate freq		field replacement	SECT	= section(s)		
BWO	 backward wave oscillator 		= impregnated	NSR	= not separately	SEMICON	= semiconductor		
0011		INCD	= incandescent		replaceable	SI	= silicon		
CCW CER	= counter-clockwise	INCL INS	= include(s)	OBD	and an incompanion time	SIL	- silver		
CEH CMO	<pre>= ceramic = cabinet mount only</pre>	INT	= insulation(ed) = internal	OH	= order by description	SL SPG	- slide		
COEF	= coeficient	INI	- internal	OX	= oval head = oxide	SPL	= spring = special		
COM	= common	к	= kilo=1000	UX.	oxide	SST	= stainless steel		
COMP	= composition	^	- K110-1000			SR	= split ring		
COMPL	= complete	LH	= left hand	P	= peak	STL	- steel		
CONN	= connector	LIN	= linear taper	PC	= printed circuit	312	31661		
CP	= cadmium plate	LK WASH	= lock washer	PF	= picofarads= 10-12	TA	= tantalum		
CRT	= cathode-ray tube	LOG	= logarithmic taper	• •	farads	TD	= time delay		
CW	= clockwise	LPF	= low pass filter	PH BRZ	= phosphor bronze	TGL	= toggle		
			,	PHL	= phillips	THD	= thread		
DEPC	= deposited carbon	M	= milli=10-3	PIV	= peak inverse voltage	TI	- titanium		
DR	= drive	MEG	= meg=106	PNP	= positive-negative-	TOL	= tolerance		
		MET FLM	= metal film		positive	TRIM	= trimmer		
ELECT	= electrolytic	MET OX	= metallic oxide	P/O	= part of	TWT	= traveling wave tube		
ENCAP	= encapsulated	MFR	= manufacturer	POLY	= polystyrene		-		
EXT	= external	MHZ	= mega hertz	PORC	= porcelain	U	= micro=10-6		
		MINAT	= miniature	POS	= position(s)				
F	= farads	MOM	= momentary	POT	= potentiometer	VAR	= variable		
FH	= flat head	MOS	= metal oxide substrate	PP	= peak-to-peak	VDCW	- dc working volts		
FIL H	= fillister head	MTG	= mounting	PT	= point				
FXD	= fixed	MY	= "mylar"	PWV	= peak working voltage	W /	= with		
_						w	= watts		
G	= giga (109)	N	= nano (10-9)	RECT	= rectifier	WIV	= working inverse		
GE	= germanium	N/C	= normally closed	RF	 radio frequency 		voltage		
GL	= glass	NE	= neon	RH	= round head or	ww	= wirewound		
GRD	= ground(ed)	NI PL	= nickel plate		right hand	W/O	= without		

Table 6-2. Replaceable Parts

Ref. Des.	HP Part Number	C O	Qty	Description	Mfr. Code	Mfr. Part Number
A1 C1 C2,4 C3 H1	64515-66505 0180-0374 0160-5321 0160-5315 2360-0113	0 5 0 2	1 1 2 1 8	PC BOARD ASSEMBLY CF TA 10UF 20V CF CE .01UF 100V CF CE 3300PF 100V MS 6-32 .250LG	28480 28480 28480 28480 28480	64515-66505 0180-0374 0160-5321 0160-5315 2360-0113
H2 H3 H4 H5 J1	3050-0425 2260-0009 0570-0661 0380-0162 1200-0870	3 8 1 9	3 1 4 1	WFL .125 .312 .04 NUTH 4-40 .093 SCREW-THUMB SPRC 6-32 .750 ZIF SCKT 28 PIN	28480 28480 28480 28480 28480	3050-0425 2260-0009 0570-0661 0380-0162 1200-0870
MP1 MP2 MP3 MP4 MP5	64500-04101 64500-45205 5041-1576 64515-00204 64500-09101	5 6 0 8 5	1 1 1 1	COVER-SAFETY BATHTUB 28 PANEL-SUPPORT PANEL INTEL 27256 GROUND CLIP	28480 28480 28480 28480 28480	64500-04101 64500-45205 5041-1576 64515-00204 00180-09104
R1 R2 R3 RP1 RP2	0757-0401 0757-0412 0757-0420 1810-0279 1810-0280	0 3 3 5 8	1 1 1 1	RF .12MF 100 RF .12MF 365 RF .12MF 750 RES NET-4.7K x 9 RES NET-10K x 9	28480 28480 28480 01121 01121	0757-0401 0757-0412 0757-0420 210A472 210A103
V1 V2	1820-1416 1820-2102	5 8	1	IC INVERTER IC 8 BIT LATCH	18324 18324	74LS14 74LS373N

Table 6-3. Manufacturers' Codes

Mfr. No.	Manufacturer Name	Address	Zip	Code
28480	Hewlett-Packard Corp.	Palo Alto	Ca	94304
01121	Allen-Bradley Co.	Milwaukee	Wi	53204
18324	Signetics Corp.	Sunnyvale	Ca	94086
04222	AVX Ceramics Corp.	Myrtle Beach	SC	29577
19613	Textool Products INC.	Irving	Tx	75060
24546	Corning Glass Works	Bradford	Pa	16701

SECTION VII

BACKDATING

7-1. There is no backdating information applicable to the 64515C PROM Programmer Module at the publication date of this manual.

SECTION VIII

SERVICE

- 8-1. INTRODUCTION.
- 8-2. The 64515C PROM Programmer Module provides the electrical interface between the 64501A PROM Programmer Controller and the PROM chip being programmed, verified or read. The PROM programmer circuits are contained on one PC board (HP P/N 64515-66504 or 64515-66505).
- 8-3. Figure 8-1, 8-2 and 8-3 are timing diagrams, figure 8-5 is a detailed schematic diagram and figure 8-4 is the component locator for the 64515C PC board.
- 8-4. THEORY.
- 8-5. GENERAL. The PROM Programmer circuits provide the following basic functions:
 - a. Multiplexes via latch U1 the low order address bits to provide 14 address bits (A0 out A13 out) to the EPROM chip. The Intel 2764/2764A and TMS 2564 use only 13 of the address bits.
 - Since the Intel 27128/27128A is a 128K EPROM, an extra address bit is provided (A13) and the Intel 27256 requires 2 extra address bits (A13 and A14) to address its 256K memory locations (8 X 32K).
 - b. Uses the programming voltage signal (VP3) from the Controller PCB in conjunction with control bits A13 in, A14 in, and LP2 (2564 uses A4 in also) to generate the control signals neccessary to program the EPROM chip.
 - c. Generates the "1D HEX" ID code (IDO-ID4).
 - d. Routes "programming" data (DWO-DW7) from the Controller PCB to the EPROM chip.
 - e. Provides current sinking thru RP2 and current sourcing thru RP1 in the quiescient state for DW0-DW7 and DR0-DR7 data lines.
 - f. Routes "read" data (DRO-DR7) from EPROM chip back to the Controller PCB during verification and normal reading. It should be noted that the verification of all data programmed into the EPROM takes place after the chip has been programmed and not during the programming sequence.

- 8-6. ADDRESSING, WRITING and READING CIRCUITS. Thirteen bits of addressing (AO out A12 out) are used for selecting any one of the 8192 internal memory locations in the 2564 and 2764/2764A memories. A fourteenth bit A13 out is provided to address the 16K bytes of memory in 27128/27128A EPROM and address bits A13 and A14 out are provided to address the 32K bytes of memory in the Intel 27256 EPROM.
- 8-7. The low-order bits (A0 out A7 out) are latched from the Controller PCB using Latch U1 on the 64515C PCB , then the high-order bits (A8 out A12 out) are multiplexed with low addresses A0-A4 and bypasses Latch U1 so that thirteen address lines address the EPROM on only eight address lines. The 27128/27128A chip uses A10 in from the EPROM Programmer Controller board for A13 out due to the chip size (16K x 8). The 27256 chip uses also A13 out and A14 out (32K x 8).
- 8-8. PROM MODULE ID. The final function provided by the 64515C PCB is the generation of the 1D HEX ID code. This is done by grounding ID0, ID2, ID3 and ID4 while tying ID1 to +5 V. Since ID0 is the LSB, this produces 00010 which becomes 11101 since the ID signals are low true. This is equivalent to decimal 29 (1D HEX).
- 8-9. PROGRAMMING SEQUENCE. In brief, the programming process consists of: 1) activating the program mode, 2) applying the lower 8 bits of address and latching them into U2, 3) applying the upper 5 bits of address via the lower 5 bits A0-A4 (multiplexing 13 bits on 8 lines), 4) applying data and VPP, 5) applying the programming pulse. Each 8-bit word is programmed completely into a specific location before moving on to the next and repeating steps 1 thru 5.

Table 8-1. MODE Selection

	MODE		CE	ŌĒ	PGM	VPP	VCC	OUTPUTS
	Read		V low	V low	V hi	Vcc	Vcc	D out
	Standby		V hi	X	X	Vcc	Vcc	High Z
##	Program		V low	V hi	V low	Vpp	Vcc	Din
	Program	Verify	V low	V low	V hi	Vpp	Vcc	D out
	Program	Inhibit	V hi	X	X	Vpp	Vcc	High Z

X can be either V low or V hi

NOTE

There is no "Program" pin on the 27256

Table 8-2. Program/Verify Sequence for the 2564

- 1. Press the [prom prog] softkey. Select the 2564 EPROM (softkey).
- 2. Initial conditions: a) VPP = +1.2 VDC
 - b) $\overline{CE} = +5 \text{ VDC}$
 - c) $\overline{CS1}/\overline{CS2} = 0$ VDC
 - d) $\overline{PGM} = 0 \text{ VDC}$
- 3. Insert EPROM chip into ZIF socket J1.
- 4. VPP (VP3) gets raised to +5 VDC.
- 5. Apply address for bit location to be programmed.
- 6. Latch lower 8 bits of address then pass upper bits of address.
- 7. Apply data to Bus (bits DWO-DW7).
- 8. Apply programming power. VPP goes to +21 Volts.
- 9. PGM is the programming signal and is brought low for 50 mS.
- 10. Lower programming power (VPP goes to +5 VDC).
- 11. Repeat step 4 through 8 to program remaining data into PROM memory.
- 12. The Verify Sequence will begin and run through all the previously programmed locations of memory. A failure message will be displayed if any memory location was not programmed correctly.

NOTE

Programmer should be at conditions of step 1 when PROM chip is removed from ZIF socket J1.

Table 8-3. Program/Verify Sequence for the 2764/2764A, 27128/27128A

- 1. Press the [prom_prog] softkey. Select the 2764, 2764A, 27128, or the 27128A EPROM (softkey).
- 2. Initial conditions: a) VPP = +1.2 VDC
 - b) $\overline{CE} = +5 \text{ VDC}$
 - c) $\overline{OE} = +5 \text{ VDC}$
 - d) $\overline{PGM} = 0 VDC$
- 3. Insert EPROM chip into ZIF socket J1.
- 4. VPP gets raised to +5 VDC.
- 5. Apply address for bit location to be programmed.
- 6. Latch lower 8 bits of address then pass upper bits of address.
- 7. Apply data to Bus (bits DWO-DW7).
- 8. Apply programming power. VPP goes to +21 volt (11.5 volts for 2764A/27128A).
- 9. CE goes low for duration of programming sequence
- 9. PGM is the programming signal and goes low for 1 mS initially.
- 10. OE goes low and a Verify Sequence takes place. If the Verify Sequence fails, the PROM is reprogrammed and a Verify Sequence takes place again. The Programm/Verify Sequence (steps 9 and 10) will occur for up to 15 failures and then drop out of the program mode. When/if the PROM passes the verify test, it then will be programmed X number of times (X = the number of times the PROM went through the program/verify sequence).
- 11. Lower programming power (VPP goes to +5 VDC).
- 12. Repeat step 4 through 11 to program remaining data into PROM memory.
- 13. The Read/Verify Sequence will begin and run through all the previously programmed locations of memory. A failure message will be displayed if any memory location was not programmed correctly.

Table 8-4. Program/Verify Sequence for the 27256

- 1. Press the [prom prog] softkey. Select the 27256 EPROM (softkey).
- 2. Initial conditions: a) VPP = +1.2 VDC
 - b) $\overline{CE} = +5 \text{ VDC}$
 - c) $\overline{OE} = +5 \text{ VDC}$
 - d) $\overline{PGM} = 0$ VDC
- 3. Insert EPROM chip into ZIF socket J1.
- 4. VPP gets raised to +5 VDC.
- 5. Apply address for bit location to be programmed.
- 6. Latch lower 8 bits of address then pass upper bits of address.
- 7. Apply data to Bus (bits DWO-DW7).
- 8. Apply programming power. VPP goes to +12 Volt.
- 9. $\overline{\text{CE}}$ is the programming signal and goes low for 1 mS initially.
- 10. OE goes low and a Verify Sequence takes place. If the Verify Sequence fails, the PROM is reprogrammed and a Verify Sequence takes place again. The Programm/Verify Sequence (steps 9 and 10) will occur for up to 15 failures and then drop out of the program mode. When/if the PROM passes the verify test, it then will be programmed X number of times (X = the number of times the PROM went through the program/verify sequence).
- 11. Lower programming power (VPP goes to +5 VDC).
- 12. Repeat step 4 through 11 to program remaining data into PROM memory.
- 13. The Verify Sequence will begin and run through all the previously programmed locations of memory. A failure message will be displayed if any memory location was not programmed correctly.





Figure 8-1. Timing Diagram for the 2564






Figure 8-3. Timing Diagram for the 2764/2764A and 27128/27128A




Figure 8-4. Model 64515C Illustrated Parts Breakdown





Figure 8-5. Model 64515C Component Locator



ICs ON THIS SCHEMATIC


Ref Desig	HP Part No.	Mfr Part No.
U1	1820-2102	74S373
U2	1820-1149	74S04

PARTS ON THIS SCHEMATIC

C1-4 J1 R1-3 RP1,2 U1,2	

NOTE "A"			
IC	Pin T	o Function	
2764 2764A	22 20 27 26 2 23 21	OE CE PGM NC A12 A11 A10	
2564	22 20 27 26 2 23 21	PD/PGM A11 CS2 Vcc CS1 A12 A10	
27128 27128A	22 20 27 26 2 23 21	OE CE PGM A13 A12 A11 A10	
27256	22 20 27 26 2 23 21	OE CE A14 A13 A12 A11 A10	

POWER CONFIGURATION



Arranged alphabetically by country



Product Line Sales/Support Key

Key Product Line

A Analytical

CM Components

C Computer Systems Sales only

CH Computer Systems Hardware Sales and Services

CS Computer Systems Software Sales and Services

E Electronic Instruments & Measurement Systems

M Medical Products

P Personal Computation Products

* Sales only for specific product line

** Support only for specific product line

IMPORTANT:These symbols designate general product line capability. They do not insure sales or support availability for all products within a line, at all locations. Contact your local sales office for information regarding locations where HP support is available for specific products.

HP distributors are printed in italics.

HEADQUARTERS OFFICES

If there is no sales office listed for your area, contact one of these headquarters offices.

AFRICA AND MIDDLE EAST

Hewlett-Packard S.A. Mediterranean and Middle East Operations Atrina Centre 32 Kifissias Ave.

Paradissos-Amarousion, ATHENS

Greece Tel: 682 88 11

Telex: 21-6588 HPAT GR Cable: HEWPACKSA Athens

NORTH/CENTRAL AFRICA

Hewlett-Packard S.A. 7, Rue du Bois-du-Lan CH-1217 **MEYRIN** 2, Switzerland Tel: (022) 83 12 12 Telex: 27835 hpse

Cable: HEWPACKSA Geneve

ASIA

Hewlett-Packard Asia Ltd. 47/F, 26 Harbour Rd., Wanchai, HONG KONG G.P.O. Box 863, Hong Kong Tel: 5-8330833 Telex: 76793 HPA HX Cable: HPASIAL TD

CANADA

Hewlett-Packard (Canada) Ltd. 6877 Goreway Drive MISSISSAUGA, Ontario L4V 1M8 Tel: (416) 678-9430

Telex: 610-492-4246

EASTERN EUROPE

Hewlett-Packard Ges.m.b.h. Lieblgasse 1 P.O.Box 72 A-1222 **VIENNA**, Austria Tel: (222) 2365110 Telex: 1 3 4425 HEPA A

NORTHERN EUROPE

Hewlett-Packard S.A. Uilenstede 475 P.O.Box 999 NL-1180 AZ AMSTELVEEN The Netherlands

Tel: 20 437771

SOUTH EAST EUROPE

Hewlett-Packard S.A. World Trade Center 110 Avenue Louis Carol 1215 Cointrin, **GENEVA**, Switzerland

Tel: (022) 98 96 51 Telex: 27225 hpse.

EASTERN USA

Hewlett-Packard Co. 4 Choke Cherry Road **ROCKVILLE**, MD 20850 Tel: (301) 258-2000

MIDWESTERN USA

Hewlett-Packard Co. 5201 Tollview Drive ROLLING MEADOWS, IL 60008 Tel: (312) 255-9800

SOUTHERN USA

Hewlett-Packard Co. 2000 South Park Place P.O. Box 105005 ATLANTA, GA 30348 Tel: (404) 955-1500

WESTERN USA

Hewlett-Packard Co. 3939 Lankershim Blvd. P.O. Box 3919 LOS ANGELES, CA 91604 Tel: (213) 506-3700

OTHER INTERNATIONAL AREAS

Hewlett-Packard Co. Intercontinental Headquarters 3495 Deer Creek Road PALO ALTO, CA 94304 Tel: (415) 857-1501 Telex: 034-8300

Cable: HEWPACK

ANGOLA

Telectra
Empresa TAEcnica de Equipamentos
R. Barbosa Rodrigues, 41-I DT.
Caixa Postal 6487
LUANDA
Tel: 35515.35516

E.P

ARGENTINA

Hewlett-Packard Argentina S.A. Avenida Santa Fe 2035 Martinez 1640 BUENOS AIRES Tel: 798-5735, 792-1293 Cable: HEWPACKARG A,E,CH,CS,P

AUSTRALIA

Adelaide, South Australia Office

Hewlett-Packard Australia Ltd. 153 Greenhill Road PARKSIDE, S.A. 5063 Tel: 272-5911 Telex: 82536

Cable: HEWPARD Adelaide A*,CH,CM,CS,E,M,P

Brisbane, Queensland Office

Hewlett-Packard Australia Ltd. 10 Payne Road

THE GAP, Queensland 4061 Tel: 30-4133 Telex: 42133

Cable: HEWPARD Brisbane A,CH,CS,CM,E,M,P

Canberra, Australia Capital Territory Office

Hewlett-Packard Australia Ltd. 121 Wollongong Street FYSHWICK, A.C.T. 2609 Tel: 80 4244

Telex: 62650 Cable: HEWP

Cable: HEWPARD Canberra C,CH,CM,CS,E,P

Melbourne, Victoria Office

Hewlett-Packard Australia Ltd. 31-41 Joseph Street BLACKBURN, Victoria 3130

Tel: 895-2895 Telex: 31-024

Cable: HEWPARD Melbourne A,CH,CM,CS,E,M,P

Perth, Western Australia Office

Hewlett-Packard Australia Ltd. 261 Stirling Highway CLAREMONT, W.A. 6010 Tel: 383-2188

Telex: 93859

Cable: HEWPARD Perth A,CH,CM,CS,E,M,P

Sydney, New South Wales Office

Hewlett-Packard Australia Ltd. 17-23 Talavera Road P.O. Box 308 NORTH RYDE, N.S.W. 2113 Tel: 888-4444

Telex: 21561 Cable: HEWPARD Sydney A,CH,CM,CS,E,M,P

AUSTRIA

Hewlett-Packard Ges.m.b.h. Grottenhofstrasse 94 A-8052 **GRAZ** Tel: (0316) 291 5 66 Telex: 32375 CH.E

Hewlett-Packard Ges.m.b.h. Lieblgasse 1 P.O. Box 72 A-1222 VIENNA Tel: (0222) 23 65 11-0 Telex: 134425 HEPA A A,CH,CM,CS,E,M,P

BAHRAIN

Green Salon P.O. Box 557 Manama BAHRAIN Tel: 255503-255950 Telex: 84419

Telex: 84419
P
Wael Pharmacy

P.O. Box 648

BAHRAIN

Tel: 256123

Telex: 8550 WAEL BN
E.M

BELGIUM

Hewlett-Packard Belgium S.A./N.V. Blvd de la Woluwe, 100 Woluwedal B-1200 **BRUSSELS** Tel: (02) 762-32-00 Telex: 23-494 paloben bru A,CH,CM,CS,E,M,P

BERMUDA

Applied Computer Technologies Atlantic House Building Par-La-Ville Road Hamilton 5 Tel: 295-1616

BRAZIL

Hewlett-Packard do Brasil I.e.C. Ltda. Alameda Rio Negro, 750 Alphaville 06400 **BARUERI SP** Tel: (011) 421.1311 Telex: (011) 33872 HPBR-BR Cable: HEWPACK Sao Paulo

A,CH,CM,CS,E,M,P

Arranged alphabetically by country

BRAZIL (Cont'd)

Hewlett-Packard do Brasil Le.C. Ltda. Avenida Epitacio Pessoa, 4664

22471 RIO DE JANEIRO-RJ Tel: (02I) 286.0237

Telex: 021-21905 HPBR-BR Cable: HEWPACK Rio de Janeiro

A,CH,CM,E,M,P* Convex/Van Den Rua Jose Bonifacio 458 Todos Os Santos CEP 20771 RIO DE JANEIRO, RJ

Tel: 249-7121, 591-4946

Telex: 33487

ANAMED I.C.E.I. Ltda. Rua Bage, 103 04012 SAO PAULO Tel: (011) 570-5726 Telex: 021-21905 HPBR-BR

CANADA

Alberta

Hewlett-Packard (Canada) Ltd. 3030 3rd Avenue N.E. CALGARY, Alberta T2A 6T7

Tel: (403) 235-3100 A,CH,CM,E*,M,P

Hewlett-Packard (Canada) Ltd. 11120-178th Street

EDMONTON, Alberta T5S 1P2 Tel: (403) 486-6666 A,CH,CM,CS,E,M,P

British Columbia

Hewlett-Packard (Canada) Ltd. 10691 Shellbridge Way RICHMOND,

British Columbia V6X 2W7 Tel: (604) 270-2277 Telex: 610-922-5059 A,CH,CM,CS,E*,M,P*

Hewlett-Packard (Canada) Ltd. 121 - 3350 Douglas Street VICTORIA, British Columbia V8Z 3L1 Tel: (604) 381-6616 CH,CS

Manitoba

Hewlett-Packard (Canada) Ltd. 1825 Inkster Blvd. WINNIPEG, Manitoba R3H 0Y1 Tel: (204) 786-6701 A,CH,CM,E,M,P*

New Brunswick

Hewlett-Packard (Canada) Ltd. 37 Shediac Road MONCTON, New Brunswick E1A 2R6 Tel: (506) 855-2841 CH CS

Nova Scotia

Hewlett-Packard (Canada) Ltd. Suite 111 900 Windmill Road **DARTMOUTH, Nova Scotia B2Y 3Z6** Tel: (902) 469-7820 CH,CM,CS,E*,M,P*

Ontario

Hewlett-Packard (Canada) Ltd. 3325 N. Service Rd., Unit 6 **BURLINGTON, Ontario P3A 2A3** Tel: (416) 335-8644 CS,M3

Hewlett-Packard (Canada) Ltd. 496 Days Road

KINGSTON, Ontario K7M 5R4 Tel: (613) 384-2088

Hewlett-Packard (Canada) Ltd. 552 Newbold Street LONDON, Ontario N6E 2S5 Tel: (519) 686-9181 A,CH,CM,E*,M,P*

Hewlett-Packard (Canada) Ltd. 6877 Goreway Drive

MISSISSAUGA, Ontario L4V 1M8 Tel: (416) 678-9430

A,CH,CM,CS,E,M,P

Hewlett-Packard (Canada) Ltd. 2670 Queensview Dr. OTTAWA, Ontario K2B 8K1 Tel: (613) 820-6483 A,CH,CM,CS,E*,MS,P*

Hewlett-Packard (Canada) Ltd. 1855 Lasalle Boulevard

SUDBURY, Ontario, P3A 2A3 Tel: (705) 560-5450 CH

Hewlett-Packard (Canada) Ltd. 220 Yorkland Blvd, Unit #11 WILLOWDALE, Ontario M2J 1R5 Tel: (416) 499-9333

Quebec Hewlett-Packard (Canada) Ltd.

Trans-Canada Highway KIRKLAND, Quebec H9J 2M5 Tel: (514) 697-4232 A.CH.CM.CS.E.M.P* Hewlett-Packard (Canada) Ltd. 1150 Rue Claire Fontaine

17500 South Service Road

QUEBEC CITY, Quebec G1R 5G4 Tel: (418) 648-0726

Hewlett-Packard (Canada) Ltd. #7-130 Robin Crescent

SASKATOON, Saskatchewan S7L 6M7 Tel: (306) 242-3702 CH,CS

CHILE

ASC Ltda Austria 2041 **SANTIAGO**

Tel: 223-5946, 223-6148 Telex: 340192 ASC CK

Jorge Calcagni y Cia. Ltda. Av. Italia 634 Santiago Casilla 16475

SANTIAGO 9 Tel: 222-0222

Telex: 440283 JCYCL CZ CM,E,M

Metrolab S.A. Monjitas 454 of. 206 SANTIAGO

Tel: 395752, 398296 Telex: 340866 METLAB CK

Olympia (Chile) Ltda. Av. Rodrigo de Araya 1045 Casilla 256-V

SANTIAGO 21 Tel: 225-5044

Telex: 340892 OLYMP

Cable: Olympiachile Santiagochile CH.CS.P

CHINA, People's Republic of

China Hewlett-Packard Co., Ltd. 6th Floor, Sun Hung Kai Centre 30 Harbour Road

HONG KONG

Tel: 5-8323211 Telex: 36678 HEWPA HX A,C,CH,CS,E,M,P

China Hewlett-Packard Rep. Office P.O. Box 418

1A Lane 2, Luchang St. Beiwei Rd., Xuanwu District

BEIJING Tel: 33-1947, 33-7426 Telex: 22601 CTSHP CN

Cable: 1920 A,CH,CM,CS,E,P

COLOMBIA

InstrumentaciAOn H. A. Langebaek & Kier S.A. Carrera 4A No. 52A-26 Apartado Aereo 6287 BOGOTA 1, D.E. Tel: 212-1466

Telex: 44400 INST CO Cable: AARIS Bogota CM.E.M

Nefromedicas Ltda.

Calle 123 No. 9B-31 Apartado Aereo 100-958 BOGOTA D.E., 10 Tel: 213-5267, 213-1615

Telex: 43415 HEGAS CO

Procesa, S.A. CRA 7 No. 24-89 Piso 25 Torre Colpatria Apartado Aereo No. 49667

BOGOTA D.E. Tel: 2344925, 2344958, 2344742

Telex: 43127 COVER CO

Compumundo Avenida 15 # 107-80 BOGOTA D.E. Tel: 214-4458 Telex: 45466 MARICO **COSTA RICA**

Cientifica Costarricense S.A. Avenida 2, Calle 5 San Pedro de Montes de Oca Apartado 10159

SAN JOSÉ

Tel: 24-38-20, 24-08-19 Telex: 2367 GALGUR CR CM,E,M

CYPRUS

Telerexa Ltd. P.O. Box 4809 14C Stassinos Avenue NICOSIA

Tel: 62698

Telex: 2894 LEVIDO CY FMP

DENMARK

Hewlett-Packard A/S Datavej 52 DK-3460 BIRKEROD Tel: (02) 81-66-40 Telex: 37409 hpas dk A,CH,CM,CS,E,M,P Hewlett-Packard A/S Rolighedsvej 32 DK-8240 RISSKOV, Aarhus

Tel: (06) 17-60-00 Telex: 37409 hpas dk

CH.E

DOMINICAN REPUBLIC

Microprog S.A. Juan Tomás Mejía y Cotes No. 60 Arrovo Hondo SANTO DOMINGO Tel: 565-6268

Telex: 4510 ARENTA DR (RCA)

ECUADOR

CYFDF Cia. Ltda. Avenida Eloy Alfaro 1749 y Belgica Casilla 6423 CCI

Tel: 450-975, 243-052 Telex: 2548 CYEDE ED

CM,E,P Hospitalar S.A. Robles 625 Casilla 3590 QUITO

Tel: 545-250, 545-122 Telex: 2485 HOSPTL ED Cable: HOSPITALAR-Quito

QUITO

Tel: 2-238-951 Telex: 2298 ECUAME ED

Egyptian International Office for Foreign Trade P.O. Box 2558 42 El-Zahraa Street Dokki, CAIRO, Tel: 712230

Telex: 93337 EGPOR UN Cable: EGYPOR

P,A

EGYPT (Cont'd)

INFORMATIC FOR SYSTEMS 22 Talaat Harb Street CAIRO,

Tel: 759006

Telex: 93697 SAFLM UN

CS

International Engineering Associates 24 Hussein Hegazi Street

Kasr-el-Aini CAIRO,

Tel: 23829, 21641 Telex: 93830 IEA UN Cable: INTEGASSO

Ε

S.S.C. Medical 40 Gezerat El Arab Street Mohandessin

CAIRO, Tel: 803844, 805998.

Tel: 803844, 805998, 810263 Telex: 20503 SSC UN

М*

EL SALVADOR

IPESA de El Salvador S.A. 29 Avenida Norte 1216 SAN SAL VADOR Tel: 26-6858, 26-6868 Telex: 20539 IPESASAL A,CH,CM,CS,E,P

FINLAND

Hewlett-Packard Oy Piispankalliontie 17 02200 **ESPOO** Tel: 00358-0-88721 Telex: 121563 HEWPA SF CH,CM,SS,P

Hewlett-Packard Oy (Olarinluoma 7) PL 24 02101 **ESPOO** 10 Tel: (90) 4521022

A,E,M

Hewlett-Packard Oy Aatoksenkatv 10-C SF-40720-72 JYVASKYLA Tel: (941) 216318

CH

Hewlett-Packard Oy Kainvuntie 1-C SF-90140-14 **OULU** Tel: (981) 338785 CH

FRANCE

Hewlett-Packard France Z.I. Mercure B Rue Berthelot F-13763 Les Milles Cedex AIX-EN-PROVENCE

Tel: (42) 59-41-02 Telex: 410770F A,CH,E,M,P*

Hewlett-Packard France 64, rue Marchand Saillant F-61000 ALENCON Tel: (33) 29 04 42 Hewlett-Packard France Boite Postale 503 F-25026 BESANCON 28 rue de la Republique F-25000 BESANCON Tel: (81) 83-16-22

Telex: 361157 CH,M

Hewlett-Packard France
13, Place Napoleon III
F-29000 BREST
Tel: (98) 03-38-35
Hewlett-Packard France
Chemin des Mouilles
Boite Postale 162
F-69130 ECULLY Cedex (Lyon)

Tel: (78) 833-81-25

Telex: 310617F A,CH,CS,E,M

Hewlett-Packard France
Parc d'Activite du Bois Briard

Ave. du Lac F-91040 **EVRY** Cedex Tel: 6 077-8383 Telex: 692315F

Ε

Hewlett-Packard France 5, Avenue Raymond Chanas F-38320 **EYBENS** (Grenoble) Tel: (76) 62-67-98

Telex: 980124 HP GRENOB EYBE

CH

Hewlett-Packard France Centre d'Affaire Paris-Nord Bâtiment Ampère 5 étage Rue de la Commune de Paris

Boite Postale 300 F-93153 LE BLANC MESNIL

Tel: (1) 865-44-52 Telex: 211032F CH,CS,E,M

Hewlett-Packard France Parc d'Activités Cadera Quartier Jean Mermoz

Avenue du Président JF Kennedy F-33700 MERIGNAC (Bordeaux)

Tel: (56) 34-00-84 Telex: 550105F CH,E,M

Hewlett-Packard France Immueble "Les 3 B" Nouveau Chemin de la Garde ZAC de Bois Briand F-44085 NANTES Cedex Tel: (40) 50-32-22

Telex: 711085F CH**

Telex: 600048F

A,CH,CM,CS,E,M,P

Hewlett-Packard France

125, rue du Faubourg Bannier F-45000 **ORLEANS** Tel: (38) 68 01 63 Hewlett-Packard France Zone Industrielle de Courtaboeuf Avenue des Tropiques F-91947 Les Ulis Cedex **ORSAY** Tel: (6) 907-78-25 Hewlett-Packard France Paris Porte-Maillot 15, Avenue de L'Amiral Bruix F-75782 **PARIS** CEDEX 16 Tel: (1) 502-12-20 Telex: 613663F CH,M,P Hewlett-Packard France

124, Boulevard Tourasse F-64000 **PAU** Tel: (59) 80 38 02

Hewlett-Packard France 2 AllAEe de la Bourgonnette F-35100 **RENNES**

F-35100 **RENNES** Tel: (99) 51-42-44 Telex: 740912F CH,CM,E,M,P*

Hewlett-Packard France 98 Avenue de Bretagne F-76100 **ROUEN** Tel: (35) 63-57-66 Telex: 770035F

CH**,CS Hewlett-Packard France 4 Rue Thomas Mann Boite Postale 56

F-67033 STRASBOURG Cedex

Tel: (88) 28-56-46 Telex: 890141F CH,E,M,P*

Hewlett-Packard France Le PAEripole

20, Chemin du Pigeonnier de la CAEpiGEere

F-31083 **TOULOUSE** Cedex Tel: (61) 40-11-12

Telex: 531639F A,CH,CS,E,P* Hewlett-Packard France 9, rue Baudin F-26000 VALENCE

Tel: (75) 42 76 16 Hewlett-Packard France

ZAC de Bois Briand F-57640 **VIGY** (Metz) Tel: (8) 771 20 22 CH

Carolor

Hewlett-Packard France Immeuble PEricentre

F-59658 VILLENEUVE D'ASCQ Cedex

Tel: (20) 91-41-25 Telex: 160124F CH,E,M,P*

GERMAN FEDERAL REPUBLIC

Hewlett-Packard GmbH Geschäftsstelle Keithstrasse 2-4 D-1000 BERLIN 30 Tel: (030) 24-90-86 Telex: 018 3405 hpbln d A,CH,E,M,P

Hewlett-Packard GmbH Geschäftsstelle Herrenberger Strasse 130 D-7030 BÖBLINGEN Tel: (7031) 14-0 Telex: 07265739

A,CH,CM,CS,E,M,P

Hewlett-Packard GmbH Geschäftsstelle Emanuel-Leutze-Strasse 1 D-4000 DUSSELDORF Tel: (0211) 5971-1 Telex: 085/86 533 hpdd d A,CH,CS,E,M,P

Hewlett-Packard GmbH Geschäftsstelle Schleefstr. 28a

D-4600 **DORTMUND**-Aplerbeck

Tel: (0231) 45001

Hewlett-Packard GmbH Vertriebszentrale Frankfurt Berner Strasse 117 Postfach 560 140 D-6000 FRANKFURT 56 Tel: (0611) 50-04-1 Telex: 04 13249 hpffm d A,CH,CM,CS,E,M,P Hewlett-Packard GmbH

Geschäftsstelle Aussenstelle Bad Homburg Louisenstrasse 115
D-6380 BAD HOMBURG
Tel: (06172) 109-0
Hewlett-Packard GmbH
Geschäftsstelle
Kapstadtring 5

D-2000 **HAMBURG** 60 Tel: (040) 63804-1 Telex: 021 63 032 hphh d A,CH,CS,E,M,P

Hewlett-Packard GmbH Geschäftsstelle Heidering 37-39 D-3000 HANNOVER 61 Tel: (0511) 5706-0 Telex: 092 3259 A,CH,CM,E,M,P

Hewlett-Packard GmbH Geschäftsstelle Rosslauer Weg 2-4 D-6800 MANNHEIM Tel: (0621) 70050 Telex: 0462105

A,C,E Hewlett-Packard GmbH Geschäftsstelle Messerschmittstrasse 7 D-7910 NEU ULM Tel: 0731-70241

Telex: 0712816 HP ULM-D

A,C,E*

Hewlett-Packard GmbH Geschäftsstelle Ehhericherstr. 13 D-8500 NÜRNBERG 10 Tel: (0911) 5205-0 Telex: 0623 860 CH,CM,E,M,P Hewlett-Packard GmbH Geschäftsstelle

Geschäftsstelle
Eschenstrasse 5
D-8028 TAUFKIRCHEN
Tel: (089) 6117-1
Telex: 0524985
A,CH,CM,E,M,P

GREAT BRITAIN
See United Kingdom

4

SALES & SUPPORT OFFICES

Arranged alphabetically by country

GREECE

Greece

Hewlett-Packard A.E. 178, Kifissias Avenue 6th Floor Halandri-ATHENS

Tel: 6471673, 6471543, 6472971

A,CH,CM**,CS**,E,M,P

Kostas Karaynnis S.A.

8 Omirou Street

ATHENS 133 Tel: 32 30 303, 32 37 371 Telex: 215962 RKAR GR A,CH,CM,CS,E,M,P PLAISIO S.A.

Eliopoulos Brohers Ltd. 11854

ATHENS Tel: 34-51-911 Telex: 216286

GUATEMALA

IPESA Avenida Reforma 3-48, Zona 9

GUATEMALA CITY
Tel: 316627, 314786
Telex: 4192 TELTRO GU
A,CH,CM,CS,E,M,P

HONG KONG

Hewlett-Packard Hong Kong, Ltd. G.P.O. Box 795 5th Floor, Sun Hung Kai Centre 30 Harbour Road HONG KONG

Tel: 5-8323211 Telex: 66678 HEWPA HX

Cable: HEWPACK HONG KONG E,CH,CS,P

CET Ltd. 10th Floor, Hua Asia Bldg. Gloucester 64-66 Gloulester Road HONG KONG

Tel: (5) 200922 Telex: 85148 CET HX CM

Schmidt & Co. (Hong Kong) Ltd. 18th Floor, Great Eagle Centre 23 Harbour Road, Wanchai

HONG KONG Tel: 5-8330222 Telex: 74766 SCHMC HX 4 M

ICELAND

Elding Trading Company Inc. Hafnarnvoli-Tryggvagotu P.O. Box 895 IS-REYKJAVIK Tel: 1-58-20, 1-63-03

INDIA

Computer products are sold through Blue Star Ltd.All computer repairs and maintenance service is done through Computer Maintenance Corp. Blue Star Ltd. Sabri Complex II Floor 24 Residency Rd. BANGALORE 560 025 Tel: 55660

Telex: 0845-430 Cable: BLUESTAR A,CH*,CM,CS*,E Blue Star Ltd.

Band Box House

Prabhadevi

BOMBAY 400 025 Tel: 422-3101 Telex: 011-3751 Cable: BLUESTAR

Blue Star Ltd. Sahas

A.M

414/2 Vir Savarkar Marg Prabhadevi

BOMBAY 400 025 Tel: 422-6155 Telex: 011-71193 Cable: FROSTBLUE A,CH*,CM,CS*,E,M Blue Star Ltd.

Kalyan, 19 Vishwas Colony Alkapuri, BORODA, 390 005

Tel: 65235 Cable: BLUE STAR

Blue Star Ltd. 7 Hare Street CALCUTTA 700 001

Tel: 12-01-31 Telex: 021-7655 Cable: BLUESTAR

A,M

Blue Star Ltd. 133 Kodambakkam High Road

MADRAS 600 034 Tel: 82057 Telex: 041-379

Cable: BLUESTAR A,M

Blue Star Ltd.

Bhandari House, 7th/8th Floors 91 Nehru Place

NEW DELHI 110 024
Tel: 682547
Telex: 031-2463
Cable: BLUESTAR
A,CH*,CM,CS*,E,M
Blue Star Ltd.
15/16:C Wellesley Rd.
PUNE 411 011
Tel: 22775
Cable: BLUE STAR

Cable: BLUE ST. A

Blue Star Ltd. 2-2-47/1108 Bolarum Rd. SECUNDERABAD 500 003

Tel: 72057 Telex: 0155-459 Cable: BLUEFROST A.E Blue Star Ltd. T.C. 7/603 Poornima Maruthankuzhi TRIVANDRUM 695 013 Tel: 65799 Telex: 0884-259

Cable: BLUESTAR E

Computer Maintenance Corporation Ltd. 115, Sarojini Devi Road SECUNDERABAD 500 003 Tel: 310-184, 345-774

Telex: 031-2960 CH**

INDONESIA

BERCA Indonesia P.T. P.O.Box 496/Jkt. Jl. Abdul Muis 62 JAKARTA

Tel: 21-373009 Telex: 46748 BERSAL IA Cable: BERSAL JAKARTA

BERCA Indonesia P.T. P.O.Box 2497/Jkt Antara Bldg., 17th Floor

JI. Medan Merdeka Selatan 17 JAKARTA-PUSAT Tel: 21-344-181

Telex: BERSAL IA A,CS,E,M

BERCA Indonesia P.T. P.O. Box 174/SBY. Jl. Kutei No. 11 SURABAYA

Tel: 68172

Telex: 31146 BERSAL SB Cable: BERSAL-SURABAYA A*.E.M.P

IRAQ

Hewlett-Packard Trading S.A. Service Operation Al Mansoor City 9B/3/7

BAGHDAD Tel: 551-49-73

Telex: 212-455 HEPAIRAQ IK CH,CS

IRELAND

Hewlett-Packard Ireland Ltd. 82/83 Lower Leeson Street **DUBLIN** 2

Tel: 0001 608800
Telex: 30439
A,CH,CM,CS,E,M,P
Cardiac Services Ltd.
Kilmore Road
Artane
DUBLIN 5
Tel: (01) 351820
Telex: 30439
M

ISRAEL

Eldan Electronic Instrument Ltd. P.O.Box 1270 JERUSALEM 91000 16, Ohaliav St. JERUSALEM 94467 Tel: 533 221, 553 242 Telex: 25231 AB/PAKRD IL

A,M

Computation and Measurement Systems (CMS) Ltd. 11 Masad Street

67060 **TEL-AVIV** Tel: 388 388 Telex: 33569 Motil IL CH,CM,CS,E,P

ITALY

Hewlett-Packard Italiana S.p.A Traversa 99C Via Giulio Petroni, 19 I-70124 **BARI** Tel: (080) 41-07-44 M.CH

Hewlett-Packard Italiana S.p.A. Via Martin Luther King, 38/III I-40132 **BOLOGNA**

Tel: (051) 402394 Telex: 511630 CH,CS,E,M

Hewlett-Packard Italiana S.p.A. Via Principe Nicola 43G/C I-95126 CATANIA

Tel: (095) 37-10-87 Telex: 970291

Hewlett-Packard Italiana S.p.A. Via G. Di Vittorio 9

Via G. Di Vittorio 9 I-20063 CERNUSCO SUL

NAVIGLIO (Milano) Tel: (02) 923691 Telex: 334632 A,CH,CM,CS,E,M,P

Hewlett-Packard Italiana S.p.A. Via C. Colombo 49

Via C. Colombo 49 I-20090 TREZZANO SUL

NAVIGLIO (Milano) Tel: (02) 4459041 Telex: 322116 CH.CS

Hewlett-Packard Italiana S.p.A. Via Nuova San Rocco a Capodimonte, 62/A I-80131 NAPOLI Tel: (081) 7413544 Telex: 710698

A**,CH,CS,E,M Hewlett-Packard Italiana S.p.A. Viale G. Modugno 33 I-16156 GENOVA PEGLI Tel: (010) 68-37-07 Telex: 215238

E,C

Hewlett-Packard Italiana S.p.A. Via Pelizzo 15

I-35128 **PADOVA**Tel: (049) 664888
Telex: 430315
A,CH,CS,E,M

Hewlett-Packard Italiana S.p.A. Viale C. Pavese 340

I-00144 **ROMA EUR**Tel: (06) 54831
Telex: 610514
A,CH,CS,E,M,P*

ITALY (Cont'd)

Hewlett-Packard Italiana S.p.A. Via di Casellina 57/C I-50018 SCANDICCI-FIRENZE

Tel: (055) 753863

CH,E,M

Hewlett-Packard Italiana S.p.A. Corso Svizzera, 185 I-10144 TORINO Tel: (011) 74 4044

Telex: 221079 A*,CS,CH,E

JAPAN

Yokogawa-Hewlett-Packard Ltd. 152-1, Onna

ATSUGI, Kanagawa, 243 Tel: (0462) 28-0451 CM,C*,E

Yokogawa-Helwett-Packard Ltd. Meiji-Seimei Bldg. 6F 3-1 Hon Chiba-Cho **CHIBA, 280**

Tel: 472 25 7701 E,CH,CS

Yokogawa-Hewlett-Packard Ltd. Yasuda-Seimei Hiroshima Bldg. 6-11, Hon-dori, Naka-ku HIROSHIMA, 730

Tel: 82-241-0611

Yokogawa-Hewlett-Packard Ltd. Towa Building 2-3, Kaigan-dori, 2 Chome Chuo-ku

KOBE, 650 Tel: (078) 392-4791

C.E

Yokogawa-Hewlett-Packard Ltd. Kumagaya Asahi 82 Bldg 3-4 Tsukuba

KUMAGAYA, Saitama 360 Tel: (0485) 24-6563 CH,CM,E

Yokogawa-Hewlett-Packard Ltd. Asahi Shinbun Daiichi Seimei Bldg. 4-7. Hanabata-cho

KUMAMOTO, 860 Tel: (0963) 54-7311

CH.E

Yokogawa-Hewlett-Packard Ltd. Shin-Kyoto Center Bldg.

614, Higashi-Shiokoji-cho Karasuma-Nishiiru

Shiokoji-dori, Shimogyo-ku **KYOTO, 600**

Tel: 075-343-0921 CH,E

Yokogawa-Hewlett-Packard Ltd. Mito Mitsui Bldg 4-73, Sanno-maru, 1 Chome MITO, Ibaraki 310 Tel: (0292) 25-7470

Yokogawa-Hewlett-Packard Ltd. Meiji-Seimei Kokubun Bldg, 7-8 Kokubun, 1 Chome, Sendai **MIYAGI, 980** Tel: (0222) 25-1011

Telex: C,E

CH,CM,E

Yokogawa-Hewlett-Packard Ltd. Sumitomo Seimei 14-9 Bldg. Meieki-Minami, 2 Chome Nakamura-ku

NAGOYA, 450 Tel: (052) 571-5171 CH,CM,CS,E,M

Yokogawa-Hewlett-Packard Ltd. Chuo Bldg.,

4-20 Nishinakajima, 5 Chome

Yodogawa-ku **OSAKA**, 532 Tel: (06) 304-6021 Telex: YHPOSA 523-3624 A,CH,CM,CS,E,M,P*

Yokogawa-Hewlett-Packard Ltd. 27-15, Yabe, 1 Chome

SAGAMIHARA Kanagawa, 229 Tel: 0427 59-1311

Yokogawa-Hewlett-Packard Ltd. Daiichi Seimei Bldg. 7-1, Nishi Shinjuku, 2 Chome Shiniuku-ku.TOKYO 160 Tel: 03-348-4611

CH.E

Yokogawa-Hewlett-Packard Ltd. 29-21 Takaido-Higashi, 3 Chome Suginami-ku TOKYO 168 Tel: (03) 331-6111 Telex: 232-2024 YHPTOK

Yokogawa-Hewlett-Packard Ltd. Daiichi Asano Building 2-8, Odori, 5 Chome UTSUNOMIYA, Tochiqi 320 Tel: (0286) 25-7155 CH.CS.E

A,CH,CM,CS,E,M,P*

Yokogawa-Hewlett-Packard Ltd. Yasuda Seimei Nishiguchi Bldg. 30-4 Tsuruya-cho, 3 Chome YOKOHAMA 221 Tel: (045) 312-1252

CH,CM,E

Scientific and Medical Supplies Co. P.O. Box 1387

AMMAN

Tel: 24907, 39907 Telex: 21456 SABCO JO CH.E.M.P

KENYA

ADCOM Ltd., Inc., Kenya P.O.Box 30070 **NAIROBI**

Tel: 331955 Telex: 22639 E,M

KOREA

Samsung Hewlett-Packard Co. Ltd. 12 Fl. Kinam Bldg. San 75-31, Yeoksam-Dong Kangnam-Ku Yeongdong P.O. Box 72 SEOUL

Tel: 555-7555, 555-5447 Telex: K27364 SAMSAN A,CH,CM,CS,E,M,P

KUWAIT

Al-Khaldiya Trading & Contracting P.O. Box 830

SAFAT

Tel: 424910, 411726 Telex: 22481 AREEG KT Cable: VISCOUNT

E,M,A

Photo & Cine Equipment

P.O. Box 270

SAFAT Tel: 2445111

Telex: 22247 MATIN KT Cable: MATIN KUWAIT

W.J. Towell Computer Services P.O. Box 75

SAFAT Tel: 2462640/1

Telex: 30336 TOWELL KT

LEBANON

Computer Information Systems P.O. Box 11-6274

BEIRUT

Tel: 89 40 73 Telex: 42309 C,E,M,P

LUXEMBOURG

Hewlett-Packard Belgium S.A./N.V. Blvd de la Woluwe, 100 Woluwedai B-1200 BRUSSELS Tel: (02) 762-32-00 Telex: 23-494 paloben bru A,CH,CM,CS,E,M,P

MALAYSIA

Hewlett-Packard Sales (Malaysia) Sdn. Bhd.

1st Floor, Bangunan British

American

Jalan Semantan, Damansara Heights **KUALA LUMPUR 23-03**

Tel: 943022 Telex: MA31011 A,CH,E,M,P*

Protel Engineering P.O.Box 1917 Lot 6624, Section 64 23/4 Pending Road Kuching, SARAWAK

Tel: 36299 Telex: MA 70904 PROMAL Cable: PROTELENG

A,E,M

MRIEHEL

MALTA Philip Toledo Ltd. Notabile Rd.

Tel: 447 47, 455 66 Telex: Media MW 649

E.P.M **MEXICO**

Hewlett-Packard Mexicana, S.A. de C.V.

Av. Periferico Sur No. 6501 Tepepan, Xochimilco 16020 MEXICO D.F.

Tel: 6-76-46-00

Telex: 17-74-507 HEWPACK MEX A,CH,CS,E,M,P

Hewlett-Packard Mexicana, S.A.

de C.V. Czda. del Valle 409 Ote. 1 °Piso Colonia del Valle

Municipio de Garza Garciá 66220 MONTERREY, Nuevo LeAOn

Tel: 78 42 41 Telex: 038 410

Equipos Científicos de Occidente, S.A.

Av. Lazaro Cardenas 3540

GUADALAJARA Tel: 21-66-91

Telex: 0684186 ECOME

Infograficas y Sistemas del Noreste, S.A. Rio Orinoco #171 Oriente Despacho 2001

Colonia Del Valle MONTERREY

Tel: 782499, 781259A

MOROCCO

Dolbeau 81 rue Karatchi **CASABLANCA** Tel: 3041-82, 3068-38

Telex: 23051, 22822

Gerep 2 rue d'Agadir

Boite Postale 156 **CASABLANCA**

Tel: 272093, 272095 Telex: 23 739

Sema-Maroc Rue Lapebie

CASABLANCA Tel: 26.09.80 CH.CS.P

NETHERLANDS

Hewlett-Packard Nederland B.V. Van Heuven Goedhartlaan 121 NL 1181KK AMSTELVEEN P.O. Box 667 NL1180 AR AMSTELVEEN

Tel: (020) 47-20-21 Telex: 13 216 HEPA NL A,CH,CM,CS,E,M,P

Hewlett-Packard Nederland B.V. Bongerd 2

NL 2906VK CAPELLE A/D IJSSEL P.O. Box 41

NL 2900AA CAPELLE A/D IJSSEL Tel: (10) 51-64-44

Telex: 21261 HEPAC NL A,CH,CS,E

Hewlett-Packard Nederland B.V. Pastoor Petersstraat 134-136 NL 5612 LV EINDHOVEN P.O. Box 2342 NL 5600 CH EINDHOVEN Tel: (040) 326911 Telex: 51484 hepae nl

A,CH**,E,M



Arranged alphabetically by country

NEW ZEALAND

Hewlett-Packard (N.Z.) Ltd. 5 Owens Road P.O. Box 26-189 Epsom, **AUCKLAND** Tel: 687-159 Cable: HEWPAK Auckland CH,CS,CM,E,P*

Hewlett-Packard (N.Z.) Ltd. 4-12 Cruickshank Street

Kilbirnie, **WELLINGTON 3** P.O. Box 9443

Courtenay Place, **WELLINGTON 3** Tel: 877-199

Cable: HEWPACK Wellington CH,CS,CM,E,P

Northrop Instruments & Systems Ltd. 369 Khyber Pass Road

P.O. Box 8602

AUCKLAND Tel: 794-091 Telex: 60605

A.M

Northrop Instruments & Systems Ltd. 110 Mandeville St.

P.O. Box 8388

CHRISTCHURCH Tel: 488-873

Telex: 4203 A,M

Northrop Instruments & Systems Ltd. Sturdee House

85-87 Ghuznee Street P.O. Box 2406

WELLINGTON *Tel: 850-091 Telex: NZ 3380*

A,IVI

NORTHERN IRELAND See United Kingdom

NORWAY

Hewlett-Packard Norge A/S Folke Bernadottes vei 50

P.O. Box 3558

N-5033 FYLLINGSDALEN (Bergen)

Tel: 0047/5/16 55 40 Telex: 16621 hpnas n CH,CS,E,M

Hewlett-Packard Norge A/S UCOsterndalen 16-18 P.O. Box 34

N-1345 **OCUSTERÅS** Tel: 0047/2/17 11 80 Telex: 16621 hpnas n A,CH,CM,CS,E,M,P

OMAN

Khimjil Ramdas P.O. Box 19 MUSCAT

Tel: 722225, 745601

Telex: 3289 BROKER MB MUSCAT

Ρ

Suhail & Saud Bahwan

P.O.Box 169 MUSCAT

Tel: 734 201-3 Telex: 3274 BAHWAN MB

Ε

Imtac LLC P.O. Box 8676

MUTRAH

Tel: 601695 Telex: 5741 Tawoos On A,C,M

PAKISTAN

Mushko & Company Ltd. House No. 16, Street No. 16 Sector F-6/3

ISLAMABAD

Tel: 824545

Cable: FEMUS Islamabad

A,E,M,P*

Mushko & Company Ltd. Oosman Chambers Abdullah Haroon Road

KARACHI 0302 Tel: 524131, 524132 Telex: 2894 MUSKO PK Cable: COOPERATOR Karachi

A,E,M,P*
PANAMA

ElectrOnico Balboa, S.A. Calle Samuel Lewis, Ed. Alfa

Apartado 4929

PANAMA 5
Tel: 63-6613, 63-6748
Telex: 3483 ELECTRON PG
A.CM.E.M.P

PERU

Cía Electro Médica S.A. Los Flamencos 145, San Isidro

Casilla 1030 LIMA 1

Tel: 41-4325, 41-3703 Telex: Pub. Booth 25306 CM.E.M.P

SAMS

Rio De La Plata 305 SAN ISIDRO

Tel: 419928 Telex: 394 20450 PELIBERTAD

PHILIPPINES

The Online Advanced Systems Corporation Rico House, Amorsolo Cor. Herrera Street

Street

Legaspi Village, Makati P.O. Box 1510

Metro MANILA

Tel: 815-38-11 (up to 16) Telex: 63274 Online PN A,CH,CS,E,M

Electronic Specialists and Proponents Inc.

690-B Epifanio de los Santos

Avenue

Cubao, QUEZON CITY

P.O. Box 2649 Manila Tel: 98-96-81, 98-96-82, 98-96-83

Telex: 40018, 42000 ITT GLOBE MAC-KAY BOOTH

Ρ

PORTUGAL

Mundinter

Intercambio Mundial de ComAErcio S.A.R.L.

P.O. Box 2761

Av. Antonio Augusto de Aguiar 138

P-LISBON

Tel: (19) 53-21-31, 53-21-37 Telex: 16691 munter p

М

Soquimica

Av. da Liberdade, 220-2 1298 LISBOA Codex Tel: 56 21 81/2/3

Telex: 13316 SABASA

Telectra-Empresa Técnica de Equipmentos Eléctricos S.A.R.L. Rua Rodrigo da Fonseca 103 P.O. Box 2531

P-LISBON 1

Tel: (19) 68-60-72 Telex: 12598 CM,E

Rarcentro Ltda R. Costa Cabral 575 4200 PORTO Tel: 499174/495173

Telex: 26054 CH,CS

PUERTO RICO

Hewlett-Packard Puerto Rico 101 MuANoz Rivera Av Esu. Calle Ochoa HATO REY, Puerto Rico 00918

HATO REY, Puerto Rico 00918 Tel: (809) 754-7800 A,CH,CS,CM,M,E,P

QATAR

Computer Arabia P.O. Box 2750 DOHA

Tel: 883555 Telex: 4806 CHPARB

D TEIGN. 4000 CHEA

Nasser Trading & Contracting

P.O.Box 1563 DOHA

Tel: 422170 Telex: 4439 NASSER DH

M

SAUDI ARABIA

Modern Electronic Establishment Hewlett-Packard Division P.O. Box 281

Thuobah
AL-KHOBAR

Tel: 895-1760, 895-1764 Telex: 671 106 HPMEEK SJ Cable: ELECTA AL-KHOBAR

CH,CS,E,M Modern Electronic Establishment Hewlett-Packard Division

P.O. Box 1228 Redec Plaza, 6th Floor

JEDDAH *Tel: 644 38 48*

Telex: 4027 12 FARNAS SJ Cable: ELECTA JEDDAH A,CH,CS,CM,E,M,P Modern Electronic Establishment

Hewlett-Packard Division

P.O.Box 22015

RIYADH

Tel: 491-97 15, 491-63 87 Telex: 202049 MEERYD SJ CH.CS.E.M

Abdul Ghani El Ajou

P.O. Box 78 RIYADH

Tel: 40 41 717 Telex: 200 932 EL AJOU

SCOTLAND
See United Kingdom

SINGAPORE

Hewlett-Packard Singapore (Sales)

Pte. Ltd.

#08-00 Inchcape House 450-2 Alexandra Road P.O. Box 58 Alexandra Rd. Post

Office

SINGAPORE, 9115 Tel: 631788

Telex: HPSGSO RS 34209 Cable: HEWPACK, Singapore A,CH,CS,E,MS,P

Dynamar International Ltd. Unit 05-11Block 6

Kolam Ayer Industrial Estate SINGAPORE 1334 Tel: 747-6188

Telex: RS 26283 CM

SOUTH AFRICA

Hewlett-Packard So Africa (Pty.) Ltd. P.O. Box 120 Howard Place CAPE PROVINCE 7450

Pine Park Center, Forest Drive, Pinelands

CAPE PROVINCE 7405 Tel: 53-7954 Telex: 57-20006

A,CH,CM,E,M,P Hewlett-Packard So Africa (Pty.) Ltd.

P.O. Box 37099 Overport Drive 92 DURBAN 4067 Tel: 28-4178

Telex: 6-22954 CH,CM

Hewlett-Packard So Africa (Pty.) Ltd. 6 Linton Arcade 511 Cape Road

Linton Grange
PORT ELIZABETH 6001

Tel: 041-301201

Hewlett-Packard So Africa (Pty.) Ltd.

Fountain Center Kalkden Str.

Monument Park Ext 2 PRETORIA 0105

Tel: 45-5723 Telex: 32163 CH,E

SOUTH AFRICA (Cont'd)

Hewlett-Packard So Africa (Pty.) Ltd. Private Bag Wendywood SANDTON 2144

Tel: 802-5111, 802-5125 Telex: 4-20877

Cable: HEWPACK Johannesburg

A,CH,CM,CS,E,M,P

SPAIN

Hewlett-Packard Española S.A. Calle Entenza, 321 E-BARCELONA 29 Tel: 322.24.51, 321.73.54 Telex: 52603 hpbee A,CH,CS,E,M,P

Hewlett-Packard Española S.A. Calle San Vicente S/No Edificio Albia II 7B E-BILBAO 1 Tel: 423.83.06 A.CH.E.M

Hewlett-Packard Española S.A. Crta. de la Coruña, Km. 16, 400

Las Rozas E-MADRID

Tel: (1) 637.00.11 Telex: 23515 HPE CH,CS,M

Hewlett-Packard Española S.A. Avda. S. Francisco Javier, S/no Planta 10. Edificio Sevilla 2,

E-SEVILLA 5 Tel: 64.44.54 Telex: 72933 A.CS.M.P

Hewlett-Packard Española S.A. C/Isabel La Catolica, 8 E-46004 VALENCIA Tel: 0034/6/351 59 44 CH P

SWEDEN

Hewlett-Packard Sverige AB Sunnanvagen 14K S-22226 LUND Tel: (046) 13-69-79 Telex: (854) 17886 (via Spånga

office)

СН

Östra Tullgatan 3 S-21128 MALMÖ Tel: (040) 70270

Hewlett-Packard Sverige AB

Telex: (854) 17886 (via Spånga

Hewlett-Packard Sverige AB Våstra Vintergatan 9 S-70344 ÖREBRO Tel: (19) 10-48-80 Telex: (854) 17886 (via Spånga office)

Hewlett-Packard Sverige AB Skalholtsgatan 9, Kista

Box 19 S-16393 SPÅNGA Tel: (08) 750-2000 Telex: (854) 17886 Telefax: (08) 7527781 A,CH,CM,CS,E,M,P

Hewlett-Packard Sverige AB Frötallisgatan 30 S-42132 VÄSTRA-FRÖLUNDA Tel: (031) 49-09-50

Telex: (854) 17886 (via Spånga office)

SWITZERLAND

CH,E,P

Hewlett-Packard (Schweiz) AG Clarastrasse 12 CH-4058 BASEL Tel: (61) 33-59-20 Α

Hewlett-Packard (Schweiz) AG 7, rue du Bois-du-Lan Case Postale 365 CH-1217 MEYRIN 2 Tel: (0041) 22-83-11-11 Telex:27333 HPAG CH CH,CM,CS

Hewlett-Packard (Schweiz) AG Allmend 2 **CH-8967 WIDEN**

Tel: (0041) 57 31 21 11 Telex: 53933 hpag ch Cable: HPAG CH A,CH,CM,CS,E,M,P

SYRIA

General Electronic Inc. Nuri Basha Ahnaf Ebn Kays Street P.O. Box 5781

DAMASCUS Tel: 33-24-87 Telex: 411 215

Cable: ELECTROBOR DAMASCUS

Middle East Electronics P.O.Box 2308 Abu Rumnaneh DAMASCUS Tel: 33 45 92 Telex: 411 304

TAIWAN

Hewlett-Packard Taiwan Kaohsiung Office 11/F 456, Chung Hsiao 1st Road KAOHSIUNG

Tel: (07) 2412318 CH,CS,E

Hewlett-Packard Taiwan 8th Floor Hewlett-Packard Building 337 Fu Hsing North Road

TAIPEI Tel: (02) 712-0404 Telex: 24439 HEWPACK Cable: HEWPACK Taipei A,CH,CM,CS,E,M,P Ing Lih Trading Co. 3rd Floor, 7 Jen-Ai Road, Sec. 2 TAIPEI 100 Tel: (02) 3948191 Cable: INGLIH TAIPEI

THAILAND

l Inimesa

30 Patpong Ave., Suriwong

BANGKOK 5 Tel: 235-5727

Telex: 84439 Simonco TH Cable: UNIMESA Bangkok A,CH,CS,E,M

Bangkok Business Equipment Ltd. 5/5-6 Dejo Road

BANGKOK

Tel: 234-8670, 234-8671 Telex: 87669-BEQUIPT TH Cable: BUSIQUIPT Bangkok

TOGO

Societe Africaine De Promotion B.P. 12271 LOME Tel: 21-62-88

Telex: 5304

TRINIDAD & TOBAGO

Caribbean Telecoms Ltd. Corner McAllister Street & Eastern Main Road, Laventille P.O. Box 732

PORT-OF-SPAIN

Tel: 624-4213

Telex: 22561 CARTEL WG Cable: CARTEL, PORT OF SPAIN CM,E,M,P

Computer and Controls Ltd. P.O. Box 51 66 Independence Square

PORT-OF-SPAIN Tel: 623-4472

Telex: 3000 POSTLX WG

TUNISIA

Tunisie Electronique 31 Avenue de la Liberte

TUNIS Tel: 280-144 CH,CS,E,P

Corema

1 ter. Av. de Carthage **TUNIS**

Tel: 253-821

Telex: 12319 CABAM TN

TURKEY

E.M.A

Mediha Eldem Sokak No. 41/6 Yenisehir

ANKARA Tel: 319175

Telex: 42321 KTX TR Cable: EMATRADE ANKARA

Kurt & Kurt A.S. Mithatpasa Caddesi No. 75 Kat 4 Kizilay

ANKARA Tel: 318875/6/7/8

Telex: 42490 MESR TR

Saniva Bilgisayar Sistemleri A.S. Buyukdere Caddesi 103/6 Gavrettepe

ISTANBUL

Tel: 1673180 Telex: 26345 SANI TR

C.P

Teknim Company Ltd. Iran Caddesi No. 7 Kavaklidere ANKARA

Tel: 275800

Telex: 42155 TKNM TR E.CM

UNITED ARAB EMIRATES

Emitac Ltd. P.O. Box 1641 SHARJAH, Tel: 591181

Telex: 68136 EMITAC EM Cable: EMITAC SHARJAH

E,C,M,P,AEmitac Ltd.

P.O. Box 2711 ABU DHABI,

Tel: 820419-20 Cable: EMITACH ABUDHABI

Emitac Ltd. P.O. Box 8391

DUBAI, Tel: 377951 Emitac Ltd.

P.O. Box 473 RAS AL KHAIMAH, Tel: 28133, 21270

UNITED KINGDOM

GREAT BRITAIN

Hewlett-Packard Ltd. Trafalgar House **Navigation Road ALTRINCHAM**

Cheshire WA14 1NU Tel: 061 928 6422 Telex: 668068 A,CH,CS,E,M,M,P Hewlett-Packard Ltd. Miller House

The Ring, BRACKNELL Berks RG12 1XN Tel: 44344 424898 Telex: 848733

Hewlett-Packard Ltd. Elstree House, Elstree Way BOREHAMWOOD, Herts WD6 1SG

Tel: 01 207 5000 Telex: 8952716 E,CH,CS,P

Hewlett-Packard Ltd. Oakfield House, Oakfield Grove Clifton BRISTOL, Avon BS8 2BN

Tel: 0272 736806 Telex: 444302 CH,CS,E,P

Arranged alphabetically by country

GREAT BRITAIN (Cont'd)

Hewlett-Packard Ltd. **Bridewell House Bridewell Place LONDON EC4V 6BS** Tel: 01 583 6565 Telex: 298163 CH,CS,P

Hewlett-Packard Ltd. Fourier House 257-263 High Street **LONDON COLNEY**

Herts. AL2 1HA, St. Albans Tel: 0727 24400 Telex: 1-8952716 CH,CS

Hewlett-Packard Ltd. Pontefract Road

NORMANTON, West Yorkshire WF6 1RN

Tel: 0924 895566 Telex: 557355 CH,CS,P

Hewlett-Packard Ltd. The Quadrangle 106-118 Station Road REDHILL, Surrey RH1 1PS Tel: 0737 68655

Telex: 947234 CH,CS,E,P Hewlett-Packard Ltd.

Avon House 435 Stratford Road Shirley, SOLIHULL, West Midlands B90 4BL Tel: 021 745 8800

Telex: 339105 CH,CS,E,P Hewlett-Packard Ltd.

CH,CS,P

West End House 41 High Street, West End SOUTHAMPTON Hampshire S03 3DQ Tel: 04218 6767 Telex: 477138

Hewlett-Packard Ltd. King Street Lane Winnersh, WOKINGHAM Berkshire RG11 5AR Tel: 0734 784774 Telex: 847178 A,CH,CS,E,M,P

Hewlett-Packard Ltd. Nine Mile Ride Easthampstead, WOKINGHAM Berkshire, 3RG113LL Tel: 0344 773100 Telex: 848805 CH,CS,E,P

IRELAND

NORTHERN IRELAND

Hewlett-Packard Ltd. Cardiac Services Building 95A Finaghy Road South **BELFAST BT10 OBY** Tel: 0232 625-566 Telex: 747626 CH.CS

SCOTLAND

Hewlett-Packard Ltd. SOUTH QUEENSFERRY West Lothian, EH30 9TG Tel: 031 331 1188 Telex: 72682 CH,CM,CS,E,M,P

UNITED STATES

Alabama

Hewlett-Packard Co. 700 Century Park South, Suite 128 BIRMINGHAM, AL 35226 Tel: (205) 822-6802 C,CH,CS,P*

Hewlett-Packard Co. 420 Wynn Drive P.O. Box 7700 **HUNTSVILLE, AL 35807** Tel: (205) 830-2000 C,CH,CM,CS,E,M*

Alaska

Hewlett-Packard Co. 3601 C St., Suite 1234 ANCHORAGE, AK 99503 Tel: (907) 563-8855 CH.CS.E

Arizona

Hewlett-Packard Co. 8080 Pointe Parkway West PHOENIX, AZ 85044 Tel: (602) 273-8000 A,CH,CM,CS,E,M Hewlett-Packard Co. 2424 East Aragon Road TUCSON, AZ 85706 Tel: (602) 573-7400

CH.È.M** California

Hewlett-Packard Co. 99 South Hill Dr. BRISBANE, CA 94005 Tel: (415) 330-2500 CH,CS

Hewlett-Packard Co. P.O. Box 7830 (93747) 5060 E. Clinton Avenue, Suite 102 **FRESNO**, CA 93727 Tel: (209) 252-9652 CH.CS.M Hewlett-Packard Co.

1421 S. Manhattan Av. FULLERTON, CA 92631 Tel: (714) 999-6700 CH,CM,CS,E,M Hewlett-Packard Co. 320 S. Kellogg, Suite B

GOLETA, CA 93117 Tel: (805) 967-3405

Hewlett-Packard Co. 5400 W. Rosecrans Blvd. LAWNDALE, CA 90260 P.O. Box 92105 LOS ANGELES, CA 90009 Tel: (213) 643-7500 Telex: 910-325-6608

CH,CM,CS,M

Hewlett-Packard Co. 3155 Porter Drive PALO ALTO, CA 94304 Tel: (415) 857-8000 CH.CS.E Hewlett-Packard Co. 4244 So. Market Court, Suite A P.O. Box 15976 SACRAMENTO, CA 95813 Tel: (916) 929-7222

A*,CH,CS,E,M Hewlett-Packard Co. 9606 Aero Drive P.O. Box 23333 **SAN DIEGO, CA 92123** Tel: (619) 279-3200 CH,CM,CS,E,M

Hewlett-Packard Co. 2305 Camino Ramon 'C' SAN RAMON, CA 94583 Tel: (415) 838-5900 CH,CS

3005 Scott Boulevard SANTA CLARA, CA 95050 Tel: (408) 988-7000 Telex: 910-338-0586 A,CH,CM,CS,E,M Hewlett-Packard Co.

Hewlett-Packard Co.

5703 Corsa Avenue **WESTLAKE VILLAGE, CA 91362** Tel: (213) 706-6800

E*.CH*.CS* Colorado

Hewlett-Packard Co. 24 Inverness Place, East ENGLEWOOD, CO 80112 Tel: (303) 649-5000 A,CH,CM,CS,E,M

Connecticut Eff. Dec. 1, 1984 Hewlett-Packard Co. 500 Sylvan Av. BRIDGEPORT, CT 06606 Tel: (203) 371-6454

Hewlett-Packard Co. 47 Barnes Industrial Road South P.O. Box 5007 WALLINGFORD, CT 06492 Tel: (203) 265-7801 A,CH,CM,CS,E,M

Florida

CH,CS,E

Hewlett-Packard Co. 2901 N.W. 62nd Street P.O. Box 24210 FORT LAUDERDALE, FL 33307 Tel: (305) 973-2600 CH,CS,E,M,P* Hewlett-Packard Co. 4080 Woodcock Drive, Suite 132 JACKSONVILLE, FL 32207

Tel: (904) 398-0663

C*,CH*,M**

Hewlett-Packard Co. 6177 Lake Ellenor Drive P.O. Box 13910 **ORLANDO, FL 32859** Tel: (305) 859-2900 A,C,CH,CM,CS,E,P* Hewlett-Packard Co. 4700 Bayoue Blvd. Building 5 PENSACOLA, FL 32505 Tel: (904) 476-8422 A,C,CH,CM,CS,M Hewlett-Packard Co. 5550 Idlewild, #150 P.O. Box 15200 **TAMPA, FL 33684** Tel: (813) 884-3282 A*,C,CH,CS,E*,M*,P*

Georgia

Hewlett-Packard Co. 2000 South Park Place P.O. Box 105005 ATLANTA, GA 30348 Tel: (404) 955-1500 Telex: 810-766-4890 A,C,CH,CM,CS,E,M,P*

Hawaii

Hewlett-Packard Co. Kawaiahao Plaza, Suite 190 567 South King Street HONOLULU, HI 96813 Tel: (808) 526-1555 A,CH,E,M

Illinois

Hewlett-Packard Co. 304 Eldorado Road P.O. Box 1607 **BLOOMINGTON, IL 61701** Tel: (309) 662-9411 CH,M**

Hewlett-Packard Co. 525 W. Monroe, #1300 **CHICAGO, IL 60606** Tel: (312) 930-0010 CH.CS

Hewlett-Packard Co. 1200 Diehl NAPERVILLE, IL 60566 Tel: (312) 357-8800 CH*,CS

Hewlett-Packard Co. 5201 Tollview Drive **ROLLING MEADOWS, IL 60008** Tel: (312) 255-9800 Telex: 910-687-1066 A,CH,CM,CS,E,M

Indiana

Hewlett-Packard Co. 11911 N. Meridian St. **CARMEL. IN 46032** Tel: (317) 844-4100 A,CH,CM,CS,E,M

lowa

Hewlett-Packard Co. 4070 22nd Av. SW **CEDAR RAPIDS, IA 52404** Tel: (319) 390-4250 CH,CS,E,M

UNITED STATES (Cont'd)

Hewlett-Packard Co. 4201 Corporate Dr. WEST DES MOINES, IA 50265 Tel: (515) 224-1435 A**,CH,M**

Kentucky

Hewlett-Packard Co. 10300 Linn Station Road, #100 LOUISVILLE, KY 40223 Tel: (502) 426-0100 A,CH,CS,M

Louisiana

Hewlett-Packard Co. 160 James Drive East ST. ROSE, LA 70087 P.O. Box 1449 KENNER, LA 70063 Tel: (504) 467-4100 A,C,CH,E,M,P*

Maryland

Hewlett-Packard Co. 3701 Koppers Street BALTIMORE, MD 21227 Tel: (301) 644-5800 Telex: 710-862-1943 A,CH,CM,CS,E,M Hewlett-Packard Co. 2 Choke Cherry Road ROCKVILLE, MD 20850 Tel: (301) 948-6370 A,CH,CM,CS,E,M

Massachusetts

Hewlett-Packard Co. 1775 Minuteman Road ANDOVER, MA 01810 Tel: (617) 682-1500 A,C,CH,CS,CM,E,M,P* Hewlett-Packard Co. 32 Hartwell Avenue LEXINGTON, MA 02173 Tel: (617) 861-8960 CH,CS,E

Michigan Hewlett-Packard Co.

4326 Cascade Road S.E. GRAND RAPIDS, MI 49506
Tel: (616) 957-1970
CH,CS,M
Hewlett-Packard Co.
39550 Orchard Hill Place Drive
NOVI, MI 48050
Tel: (313) 349-9200
A,CH,CS,E,M
Hewlett-Packard Co.
1771 W. Big Beaver Road
TROY, MI 48084
Tel: (313) 643-6474
CH,CS

Minnesota

Hewlett-Packard Co. 2025 W. Larpenteur Ave. ST. PAUL, MN 55113 Tel: (612) 644-1100 A,CH,CM,CS,E,M

Missouri

Hewlett-Packard Co. 1001 E. 101st Terrace KANSAS CITY, MO 64131 Tel: (816) 941-0411 A,CH,CM,CS,E,M Hewlett-Packard Co. 13001 Hollenberg Drive BRIDGETON, MO 63044 Tel: (314) 344-5100 A,CH,CS,E,M

Nebraska

Hewlett-Packard 10824 Old Mill Rd., Suite 3 **OMAHA**, NE 68154 Tel: (402) 334-1813 CM,M

New Jersey

Hewlett-Packard Co. 120 W. Century Road PARAMUS, NJ 07652 Tel: (201) 265-5000 A,CH,CM,CS,E,M Hewlett-Packard Co. 20 New England Av. West PISCATAWAY, NJ 08854 Tel: (201) 981-1199 A,CH,CM,CS,E

New Mexico

Hewlett-Packard Co. 11300 Lomas Blvd.,N.E. P.O. Box 11634 **ALBUQUERQUE**, NM 87112 Tel: (505) 292-1330 CH,CS,E,M

New York

Hewlett-Packard Co. 5 Computer Drive South ALBANY, NY 12205 Tel: (518) 458-1550 A,CH,E,M Hewlett-Packard Co. 9600 Main Street P.O. Box AC CLARENCE, NY 14031 Tel: (716) 759-8621 CH,CS,E

Hewlett-Packard Co. 200 Cross Keys Office Park FAIRPORT, NY 14450 Tel: (716) 223-9950 A,CH,CM,CS,E,M Hewlett-Packard Co. 7641 Henry Clay Blvd. LIVERPOOL, NY 13088 Tel: (315) 451-1820 A,CH,CM,CS,E,M Hewlett-Packard Co. No. 1 Pennsylvania Plaza

Hewlett-Packard Co.
No. 1 Pennsylvania Plaza
55th Floor
34th Street & 8th Avenue
MANHATTAN NY 10119
Tel: (212) 971-0800
CH,CS,M*

Hewlett-Packard Co. 15 Myers Corner Rd. WAPPINGER FALLS, NY 12590 CM.E Hewlett-Packard Co. 250 Westchester Avenue WHITE PLAINS, NY 10604 Tel: (914) 684-6100 CM,CH,CS,E Hewlett-Packard Co. 3 Crossways Park West

3 Crossways Park Wes WOODBURY, NY 11797 Tel: (516) 921-0300 A,CH,CM,CS,E,M

North Carolina Hewlett-Packard Co.

305 Gregson Dr.
CARY, NC 27511
Tel: (919) 467-6600
C,CH,CM,CS,E,M,P*
Hewlett-Packard Co.
9600-H Southern Pine Blvd.
CHARLOTTE, NC 28210
Tel: (704) 527-8780
CH*,CS*
Hewlett-Packard Co.
5605 Roanne Way
P.O. Box 26500
GREENSBORO, NC 27420

Tel: (919) 852-1800

A,C,CH,CM,CS,E,M,P*

Hewlett-Packard Co.

9920 Carver Road

Ohio

CINCINNATI, OH 45242 Tel: (513) 891-9870 CH,CS,M Hewlett-Packard Co. 16500 Sprague Road CLEVELAND, OH 44130 Tel: (216) 243-7300 A,CH,CM,CS,E,M Hewlett-Packard Co. 980 Springboro Pike MIAMISBURG, OH 45343 Tel: (513) 859-8202 A,CH,CM,E*,M Hewlett-Packard Co. 675 Brooksedge Blvd. WESTERVILLE, OH 43081 Tel: (614) 436-1041 CH,CM,CS,E*

Oklahoma

Hewlett-Packard Co.

304 N. Meridian, Suite A P.O. Box 75609 OKLAHOMA CITY, OK 73147 Tel: (405) 946-9499 C,CH,CS,E*,M Hewlett-Packard Co. 3840 S. 103rd E. Ave., #100 P.O. Box 35747 TULSA, OK 74153 Tel: (918) 665-3300 A**,C,CH,CS,M*,E,P*

Oregon

Hewlett-Packard Co. 9255 S. W. Pioneer Court P.O. Box 328 WILSONVILLE, OR 97070 Tel: (503) 682-8000 A,CH,CS,E*,M

Pennsylvania

Hewlett-Packard Co. 50 Dorchester Rd. P.O. Box 6080 **HARRISBURG**, PA 17111 Tel: (717) 657-5900 C

Hewlett-Packard Co. 111 Zeta Drive PITTSBURGH, PA 15238 Tel: (412) 782-0400 A,CH,CS,E,M Hewlett-Packard Co.

Hewlett-Packard Co. 2750 Monroe Boulevard P.O. Box 713 VALLEY FORGE, PA 19482 Tel: (215) 666-9000 A,CH,CM,CS,E,M

South Carolina

Hewlett-Packard Co.
Brookside Park, Suite 122
1 Harbison Way
P.O. Box 21708
COLUMBIA, SC 29221
Tel: (803) 732-0400
A,C,CH,CS,M
Hewlett-Packard Co.
100 Executive Cntr. Dr.
Koger Executive Center
Chesterfield Bldg., Suite 124
GREENVILLE, SC 29615
Tel: (803) 297-4120

Tennessee

Hewlett-Packard Co.

One Energy Centr. #200

Pellissippi Pkwy.
P.O. Box 22490
KNOXVILLE, TN 37933
Tel: (615) 966-4747
A,C,CH,CS,M
Hewlett-Packard Co.
3070 Directors Row
MEMPHIS, TN 38131
Tel: (901) 346-8370
A,C,M
Hewlett-Packard Co.
220 Great Circle Road, Suite 116
NASHVILLE, TN 37228
Tel: (615) 255-1271
C,M,P*

Texas

CH,E*,M**

Hewlett-Packard Co. 11002-B Metric Boulevard AUSTIN, TX 78758 Tel: (512) 835-6771 C,CM,E,P* Hewlett-Packard Co. 5700 Cromo Dr P.O. Box 12903 EL PASO, TX 79913 Tel: (915) 833-4400

10

SALES & SUPPORT OFFICES

Arranged alphabetically by country

UNITED STATES (Cont'd)

Hewlett-Packard Co. 3952 Sand Shell St FORT WORTH, TX 76137 Tel: (817) 232-9500 A,C,CH,E,M

Hewlett-Packard Co. 10535 Harwin Drive P.O. Box 42816 HOUSTON, TX 77042 Tel: (713) 776-6400 A,C,CH,CS,E,M,P* Hewlett-Packard Co.

Hewlett-Packard Co. 511 W. John W. Carpenter Fwy. Royal Tech. Center #100 IRVINE, TX 75062 Tel: (214) 556-1950 C,CH,CS,E

Hewlett-Packard Co. 930 E. Campbell Rd. P.O. Box 83/1270 RICHARDSON, TX 75083-1270 Tel: (214) 231-6101 A,CH,CM,CS,E,M,P*

Hewlett-Packard Co. 1020 Central Parkway South P.O. Box 32993 SAN ANTONIO, TX 78232 Tel: (512) 494-9336 A,C,CH,CS,E,M,P*

Utah

Hewlett-Packard Co. 3530 W. 2100 South P.O. Box 26626 **SALT LAKE CITY**, UT 84126 Tel: (801) 974-1700 A.CH,CS,E,M

Virginia

Hewlett-Packard Co. 4305 Cox Road GLEN ALLEN, VA 23060 P.O. Box 9669 RICHMOND, VA 23228 Tel: (804) 747-7750 A,C,CH,CS,E,M,P*

Washington

Hewlett-Packard Co. 15815 S.E. 37th Street BELLEVUE, WA 98006 Tel: (206) 643-4000 A,CH,CM,CS,E,M Hewlett-Packard Co. 708 North Argonne Road P.O. Box 3808 SPOKANE, WA 99220-3808 Tel: (509) 922-7000 CH,CS

West Virginia Hewlett-Packard Co. 4604 MacCorkle Ave. CHARLESTON, WV 25304 Tel: (304) 925-0492

Wisconsin

A,M

Hewlett-Packard Co. 275 N. Corporate Dr. BROOKFIELD, WI 53005 Tel: (414) 784-8800 A,CH,CS,E*,M

URUGUAY

Pablo Ferrando S.A.C. e I. Avenida Italia 2877 Casilla de Correo 370 MONTEVIDEO

Tel: 80-2586 Telex: Public Booth 901 A.CM.E.M

Mini Computadores, Ltda. Avda. del Libertador Brig Gral Lavalleja 2071 Local 007

MONTEVIDEO

Tel: 29-55-22 Telex: 901 P BOOTH UY

Olympia de Uruguay S.A. Maquines de Oficina Avda. del Libertador 1997 Casilla de Correos 6644 MONTEVIDEO

Tel: 91-1809, 98.-3807 Telex: 6342 OROU UY

VENEZUELA

Hewlett-Packard de Venezuela C.A. 3RA Transversal Los Ruices Norte Edificio Segre 1, 2 & 3 Apartado 50933 CARACAS 1071 Tel: 239-4133

Telex: 251046 HEWPACK A.CH.CS.E.M.P

Hewlett-Packard de Venezuela C.A. Residencias Tia Betty Local 1 Avenida 3 y con calfe 75 MARACAIBO, Estado Zulia Apartado 2646

Tel: (061) 75801-75805-75806-80304

Telex: 62464 HPMAR C,E*

Hewlett-Packard de Venezuela C.A. Urb. Lomas de Este Torre Trebol — Piso 11 VALENCIA, Estado Carabobo Apartado 3347 Tel: (041) 222992/223024 CH,CS,P

Albis Venezolana S.R.L. Av. Las Marias, Ota. Alix, El Pedregal Apartado 81025 CARACAS 10804

CARACAS 1080A Tel: 747984, 742146 Telex: 24009 ALBIS VC

Tecnologica Medica del Caribe, C.A. Multicentro Empresarial del Este Ave. Libertador Edif. Libertador Nucleo "C" - Oficina 51-52

CARACAS Tel: 339867/333780 CIZUCA
Cientifica Zulia C.A.
Calle 70, Los Olivos
No. 66-86
Apartado 1843
MARACAIBO

Tel: 54-64-37, 54-63-85, 54-64-94

Telex: 62144

YUGOSLAVIA

Do Hermes General Zdanova 4 Telex: YU-11000 BEOGRAD A,CH,E,P

Hermes
Titova 50

Telex: YU-61000 **LJUBLJANA** CH.CS.E.M.P

CH,CS,E,M,P Elektrotehna Titova 51 Telex: YU-61000 **LJUBLJANA** CM

ZAMBIA

R.J. Tilbury (Zambia) Ltd. P.O. Box 32792 LUSAKA Tel: 215590 Telex: 40128

ZIMBABWE

Field Technical Sales 45 Kelvin Road, North P.B. 3458

P.B. 3458 **SALISBURY** Tel: 705 231 Telex: 4-122 RH E,P

August 1984

HP distributors are printed in italics.

